

SIEMENS

PolyBlend PB600-2

03/07

Siemens Water Technologies Corp.

PO Box 389

Bradley, IL 60915

(815) 932-8154 Phone

(815) 932-0674 Fax

TABLE OF CONTENTS

PolyBlend PB600-2

OVERVIEW

Safety Precautions.....	1
Specifications.....	1

INSTALLATION

Location.....	1
Unpacking	1
Connections.....	1
Storage.....	1

OPERATION

General.....	2
Start-Up	2
Water Pressure	2
Solution Output	2

MAINTENANCE

Shutdowns	3
Maintenance.....	3
Special Tools	3
Lubrication.....	3
Predicted Life Span.....	3
Operating Procedures.....	3
Emergency Operating Procedures.....	3
Disassembly, Repair and Reassembly	3
Recommended Spare Parts	3
Pump Replacement	3
Troubleshooting.....	4

WARRANTY	5-6
----------------	-----

APPENDIX

Differential Pressure Switch	7-8
Digital Display Controller (REM-1E)	9-10
LMI Diaphragm Pump Information	11-14
Baldor AC Motor.....	15-32
Parker Solenoid Valve	33-38

PARTS LISTS

Overall Parts List and Exploded Diagram	39-40
Mixing Chamber Assembly Parts List and Exploded Diagram.....	41-42
Flowmeter Assembly Parts List and Exploded Diagram.....	43
Pump Assembly Parts List and Exploded Diagram	45-48

DRAWINGS

General Arrangement PB600, DWG. # PB600	49
Electrical Diagram, DWG. # SES-0042.....	50

PolyBlend

Model #PB600-2

INSTALLATION, OPERATION, AND MAINTENANCE INFORMATION

CONTENTS

Overview	Warranty
Installation	Appendixes
Operation	Drawings
Maintenance	

**READ THIS MANUAL BEFORE YOU
INSTALL, OPERATE, OR SERVICE THIS
UNIT.**

OVERVIEW

SAFETY PRECAUTIONS

Ensure that the control panel is grounded to avoid possible electrical shock or damage to equipment.

Before servicing, turn off all power and assure power "lockout" to avoid possible electric shock.

Disconnect external power to the control panel before removing or replacing fuses.

SPECIFICATIONS

Pump	Diaphragm
Inlet	1" FPT, Water Supply
	5/8" Hose Barb, Polymer Supply
Outlet	1" FPT, Solution Discharge
Water Capacity	600 GPH Primary
Polymer Capacity	2.0 GPH
Pressure Rating	100 PSI
Electrical Supply	120/1/60, 10 Amps
Dimensions	32" H x 21" W x 15" D
Weight	90 lbs.
Motor(s)	(1) 1/3 HP, 120VAC, 6 AMPS

INSTALLATION

LOCATION

Select a location that provides:

- Electrical Supply
- Potable Water (Clean)
- Proximity to the Point of Use
- Easy Handling and Storage of Polymer
- Access to Unit
- Protection Against Severe Weather

UNPACKING

Examine package contents for damage. Report any to freight forwarder. Check plastic bag(s) for contents against individual packing list(s).

NOTE: Disregard any moisture; this unit was wet tested.

CONNECTIONS

- Use Teflon tape on threads. Use joint compound (pipe dope) in small amounts, if necessary.
- Do not over-tighten fittings.
- Insure that supply water pressure is **less than 100 psi.**
- Install water isolation valve with unions.
- Insure that neat polymer feed line has a **flooded suction.**

NOTE: To enhance performance, reduce the number of piping turns and elevation changes.

STORAGE

Store in atmosphere controlled environment. Protect from extreme temperature (above 110°F, 52°C, below 32°F, 0°C) and wide ambient temperature fluctuations.

Protect from direct weather exposure, i.e., sun, rain, high wind, etc.

OPERATION

GENERAL

This PolyBlend unit will perform the following functions: meter polymer dosage, regulate mixing water, provide uniform dilution and activation, operate on-line continuously, and feed solution to the point of use.

Neat polymer from the metering pump and dilution water controlled by the solenoid valve enter the mixing chamber. Dilution and activation occur, yielding prepared solution ready for use.

Neat polymer dosage rate is adjusted at pump face or at electronic controller (REM-1E, SCR, etc.). Primary dilution (and post dilution) water are controlled by individual flow control valves.

START-UP

Step 1: Switch pump to external mode at pump face.

Step 2: Prime polymer pump, using priming kit provided with unit.

Step 3: Place both power switches in Off position.

Step 4: Energize power circuit that feeds unit.

Step 5: Place main power switch in On position.

Solenoid opens. Allow mixing chamber to fill with water by opening primary dilution water control valve.

NOTE: Do not turn mixer motor on until chamber is filled with water, running dry will damage mechanical seal.

Step 6: Place mixer power switch in ON position.

Mixing chamber motor starts.

Step 7: Access REM-1E controller to turn pump On/Off for polymer output adjustment. Output can also be adjusted at pump face by varying the stroke length.

NOTE: For optimum pump performance, keep stroke frequency as high as possible. This is done by decreasing the stroke length setting. More stroke repetition with a shorter length is better than fewer strokes with a long stroke length. If stroke length is too short, pump prime may be affected.

Step 8: Adjust water flow at mixing chamber by turning control valve. (The other control valve should be turned for post-dilution adjustment, if applicable.)

NOTE: Do not run polymer pump unless water flow is established. Polymer alone can plug discharge plumbing.

WATER PRESSURE

This unit is equipped with a differential pressure switch. It has been factory set. See Appendix for details.

SOLUTION OUTPUT

Unit output is determined by setting pump stroke length and stroke frequency together with setting dilution water flow. Establish desired solution volume and solution concentration, then proceed.

EXAMPLE: 100 GPH (380 LPH) of .5% polymer solution desired. A 2 GPH (7.6 LPH) diaphragm pump is used.

— Determine neat polymer requirement.

$(100 \text{ GPH}) \times (.005) = 0.5 \text{ GPH neat polymer}$
 $(380 \text{ LPH}) \times (.005) = 1.9 \text{ LPH neat polymer}$

— Determine pump usage.

$(0.5 \text{ GPH}) \div (2 \text{ GPH}) = 25\% \text{ pump capacity}$
 $(1.9 \text{ LPH}) \div (7.6 \text{ LPH}) = 25\% \text{ pump capacity}$

— Set Controls

A 2 GPH (7.6 LPH) pump @ 100% stroke length and 25 strokes per minute will deliver 0.5 GPH (1.9 LPH). However, 2 GPH (7.6 LPH) pump @ 50% stroke length and 50 strokes per minute will also deliver 0.5 GPH (1.9 LPH) with a more homogeneous mix.

NOTE: Do not exceed polymer concentrations of 1% in the PolyBlend.

MAINTENANCE

SHUTDOWNS

If out of service more than one week, flush mixing chamber.

- Turn pump off.
- Place unit power switch in On position to establish water flow for five minutes.

If out of service for more than two weeks, flush pump and mixing chamber.

- Connect pump suction to a container of mineral oil (not water).
- Place unit power switch in On position to establish water flow.
- Turn pump on and run for three minutes.
- Turn pump off.
- Continue water flow for five additional minutes.
- Drain water from chamber and piping to prevent freezing.

MAINTENANCE

1. Clean ancillary water and/or polymer strainers weekly.
2. Flush system monthly following one week procedure.
3. Refer to the appendix for specific information on drawings, part identification, and components.

SPECIAL TOOLS

No special tools needed for operation, maintenance, and repair of components.

LUBRICATION

No lubrication is required.

PREDICTED LIFE SPAN

There is no predicted life span of wear parts as each application and operation varies.

OPERATING PROCEDURES

For normal operation, once settings are adjusted based on operation parameters, the system can simply be turned ON or OFF. Special operating instructions for Seasonal operation do not apply.

EMERGENCY OPERATING INSTRUCTIONS

Emergency operating instructions do not apply to Siemens Water Technologies – Stranco Products equipment. In case of an emergency, TURN OFF POWER TO STOP RUNNING.

DISASSEMBLY, REPAIR, & REASSEMBLY

This equipment is an open-frame design. It allows for easy removal of all components. There are no special procedures for removal of parts. If assistance is required, contact Siemens Water Technologies – Stranco Products Technical Service at 800-882-6466.

RECOMMENDED SPARE PARTS

<u>QTY.</u>	<u>PART #</u>	<u>DESCRIPTION</u>
1	SP-75HV	Pump Liquid End
1	7802910	Chamber Mechanical Seal
1	1450430	Belt, Chamber
1	1411001	Bearing, Chamber Base
1	1414001	Bearing, Chamber Top
1	38593	Pump Head

PUMP REPLACEMENT

<u>QTY.</u>	<u>PART #</u>	<u>DESCRIPTION</u>
1	AA761-75PBX	Pump

TO ORDER PARTS

You may order parts by calling, faxing or mailing your order.

Phone 800.882.6466 and ask for PolyBlend Parts.
Hours: 8 a.m. - 5 p.m., Central Time, M - F.

Fax Our fax number is 815.932.5634.

E-mail stranco.water@siemens.com

Address Siemens Water Technologies Corp.
P.O. Box 389
595 Industrial Drive
Bradley, IL 60915

TROUBLESHOOTING

Symptom	Possible Cause	Corrective Action
No Water Flow	<ul style="list-style-type: none"> • Closed Valve on Water Supply • Blocked Solenoid Valve • Closed or clogged discharge line • Rate Control Valve Closed 	<ul style="list-style-type: none"> • Make sure valve is open • Dis-assemble and clean valve • Remove any blockages or open any closed valves • Make sure valve is open
Pump won't pump Chemical	<ul style="list-style-type: none"> • Pump is turned OFF • No Water Flow • Blocked Pump Discharge Line • Back Pressure is too high • Not enough water flow 	<ul style="list-style-type: none"> • Make sure pump is in ON position • Make sure all water valves (supply and discharge) are open • Take discharge line apart, check for blockage and clean if necessary • Reduce Back pressure on unit • Increase water flow or adjust water monitoring device (flow switch, DP Switch, etc.) setpoint lower than the desired flow rate
Clogged Injection Check Valve	<ul style="list-style-type: none"> • Debris or Clumps in Polymer • Valve is stuck open allowing water into polymer line 	<ul style="list-style-type: none"> • Check polymer supply for contamination • Remove valve from chamber and clean it
Pump won't stop	<ul style="list-style-type: none"> • Water flow is still established • Pump is in internal mode 	<ul style="list-style-type: none"> • Shut off water valve or power to the unit • Switch pump to external

SIEMENS WATER TECHNOLOGIES CORP.
P.O. BOX 389
BRADLEY, IL 60915

TELEPHONE: 815-932-8154
800-882-6466
FACSIMILE: 815-932-0674

PolyBlend® Product Warranty

Siemens Water Technologies Corp. warrants equipment of its manufacture and bearing its trademark to be free of defects in material and workmanship and to materially conform to any applicable specifications and drawings approved in writing by Siemens Water Technologies. If the customer gives Siemens Water Technologies Corp. prompt written notice of a breach of this warranty within twelve (12) months from the date of start-up by an authorized Siemens Water Technologies Corp. technician or eighteen (18) months from the date of shipment, whichever occurs first (the "Warranty Period"), Siemens Water Technologies Corp. will, at its sole option and as the customer's exclusive remedy, either repair or replace free of charge, or refund the purchase price paid with respect to, any material found to be defective during the Warranty Period. No repair or replacement of defective products shall extend the Warranty Period, but any such repaired or replaced product shall be covered by the balance of the original Warranty Period. If Siemens Water Technologies Corp. determines that any claimed breach is not, in fact, covered by this warranty, the customer shall pay Siemens Water Technologies Corp.'s then customary charges for any repair or replacement.

The foregoing warranty is conditioned upon the customer's (i) the customer shall have operated and maintained the equipment in accordance with all instructions provided by Siemens Water Technologies Corp. (ii) the customer shall not have made any unauthorized repairs or alterations; (iii) the customer shall not be in default of any payment obligation to Siemens Water Technologies Corp. (iv) if requested, the customer will deliver the equipment to a Siemens Water Technologies Corp. authorized service center and the customer shall pay all inbound and outbound freight costs; (v) the customer must provide a complete and detailed description of the problem including, without limitation, the Siemens Water Technologies Corp. job number, date of delivery, date of installation, date of start-up and the operating conditions of the unit(s); (vi) return a duly completed Start-Up and Field Test Report to Siemens Water Technologies Corp. within thirty (30) days of start-up; and (vii) for equipment which is destined for extended storage, such equipment must have been stored in accordance with the Storage Requirements

detailed in the operation and maintenance manual (storage of equipment does not extend the Warranty Period).

The foregoing warranty does not extend to, and Siemens Water Technologies Corp. assumes no responsibility for, (i) the installation quality or any service defects resulting therefrom unless a Siemens Water Technologies Corp. representative or designee supervised the installation; (ii) in the event that the unit size and location are predetermined by someone other than Siemens Water Technologies Corp. or our local representative, the serviceability and/or performance of the unit for the specified design and/or actual operating conditions (this exclusion shall not apply if all necessary design information is submitted to and approved in writing by Siemens Water Technologies Corp.); (iii) any auxiliary equipment or accessories supplied by Siemens Water Technologies Corp. but manufactured by others (the original manufacturer's warranty, if any, shall apply to such products); (iv) damage to the equipment or products resulting from normal wear, abuse, neglect or operation in a manner inconsistent with Siemens Water Technologies' recommendations; and (v) damage to equipment or products that have been modified, tampered with or altered without written consent from Siemens Water Technologies.

In addition to the foregoing conditions and limitations, the following product-specific limitations and conditions must be satisfied for the foregoing warranty to apply:

1. This warranty does not cover damage caused by chemical action or abrasive material (including, without limitation, particulates in the makeup water), damage caused by handling or during transportation, or damage arising from misuse, installation or any other cause beyond Siemens Water Technologies' control. Standard units not in outdoor configurations are not warranted in outdoor applications.
2. If a non-potable water source is used as primary or secondary dilution water to the PolyBlend® unit, the warranty period shall not exceed ninety (90) days from the date of shipment.

HydroForce® Product Warranty

The HydroForce® mixing assembly, part of the PolyBlend® product line, is covered for the life of the product by the limited warranty set forth herein, provided that the limited lifetime warranty extends only to the original user of the product.

THE WARRANTIES SET FORTH ABOVE ARE SIEMENS WATER TECHNOLOGIES CORP.'S SOLE AND EXCLUSIVE WARRANTIES. SIEMENS WATER TECHNOLOGIES CORP. MAKES NO OTHER WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED,

INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE, ALL WARRANTIES ARISING FROM COURSE OF DEALING AND USAGE OF TRADE AND ALL SUCH EXPRESS OR IMPLIED WARRANTIES ARE HEREBY DISCLAIMED.

THE REMEDIES PROVIDED ABOVE ARE THE CUSTOMER'S SOLE REMEDIES FOR SIEMENS WATER TECHNOLOGIES' FAILURE TO COMPLY WITH ITS OBLIGATIONS. CORRECTION OF ANY NONCONFORMITY IN THE MANNER AND FOR THE PERIOD OF TIME PROVIDED ABOVE SHALL CONSTITUTE COMPLETE FULFILLMENT OF ALL THE WARRANTY LIABILITIES OF SIEMENS WATER TECHNOLOGIES CORP. WHETHER THE CLAIMS OF THE PURCHASER ARE BASED IN CONTRACT, IN TORT (INCLUDING NEGLIGENCE) OR OTHERWISE WITH RESPECT TO OR ARISING OUT OF THE WORK PERFORMED HEREUNDER.

LIMITATION OF LIABILITY:

NOTWITHSTANDING ANYTHING ELSE TO THE CONTRARY, SIEMENS WATER TECHNOLOGIES CORP. AND ITS SUPPLIERS AND ANY AFFILIATED COMPANIES SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL, SPECIAL, PUNITIVE OR OTHER INDIRECT DAMAGES, AND SIEMENS WATER TECHNOLOGIES' TOTAL LIABILITY ARISING AT ANY TIME FROM THE SALE OR USE OF THE EQUIPMENT SHALL NOT EXCEED THE PURCHASE PRICE PAID FOR THE EQUIPMENT. THESE LIMITATIONS APPLY WHETHER THE LIABILITY IS BASED ON CONTRACT, TORT, STRICT LIABILITY OR ANY OTHER THEORY.

Whether in or out of warranty, a Return Materials Authorization number (RMA) is required and can be obtained by calling our customer service department telephone at 800.882.6466. Have the make, model, and serial number of the item being returned. Reference the RMA number on the outside of the shipping container.

Differential Pressure Switch

Location of Differential Pressure Switch

The high pressure port connects to the inlet manifold between the solenoid valve and the rotameter/rate-adjusting valve. The low pressure port connects to the discharge side of the rotameter.

Function of Differential Pressure Switch

The differential pressure switch ensures sufficient water flow is present before the polymer pump is energized. This integral, automatic safety feature eliminates the problem of overfeeding neat polymer to an application without proper dilution.

In operation, the rate valve is adjusted to produce the desired flow through the system. This causes a pressure drop to occur across the valve which is applied to the differential pressure switch.

If supply pressure decreases enough to affect flow rate or if back pressure between the PolyBlend and the point of solution application increases enough to affect flow rate, the differential pressure across the rotameter and valve decreases. This causes power to be interrupted to the polymer pump and prevents damage to the mixing system caused by extremely high viscosity developing in the mixing chamber.

<p>NOTICE: If system pressure or flow are <u>not adequate</u>, investigate the cause of lack of flow. (For example, inadequately sized piping can produce inadequate flow.) To avoid undesirable water dilution conditions and damage to equipment, do not bypass or adjust the differential pressure switch for a lower pressure/flow setting.</p>
--

Question: *Why doesn't the polymer pump turn off when I turn the water off using the rotameter?*

The differential pressure switch senses flow on either side of a pressure drop. Because the rotameter is the sensing point, the rotameter closing is the only cause of loss of flow that the differential pressure switch cannot see.

Test the differential switch by turning off the source water or the discharge flow. (See step 5 on the next page.)

Differential Pressure Switch

Adjusting the Differential Pressure Switch

Adjust the PolyBlend differential pressure switch only if pressure and flow to the system **are adequate**.

The adjustment logic is the **opposite** of what you might expect. The PolyBlend differential pressure switches have a red light (on the left side) that lights up whenever source water flow is too low and the polymer pump is disabled. The pump stops pumping when the flow is too low. Low flow may be from lack of incoming water or from too much back pressure on the outgoing side.

	Adjustment		System Reaction
1.	Turn the PolyBlend rotameter until water flow is at maximum on the flow gauge.		
2.	Screw in the <i>differential pressure knob</i> until the red alarm light goes on.		Polymer pump is disabled.
3.	Back off the differential pressure knob until the red alarm light goes off.		The pump starts again.
4.	4a. If you want very close control of flow, leave the knob at this setting. <i>At this setting, any loss of flow (as observed by the rotameter) results in the pump being disabled.</i>	4b. If you want to make the system "more forgiving" prior to shutdown, continue to turn the knob another 1-2 turns. <i>The further you turn the knob, the more flow can be lost before the pump is disabled.</i>	Step 4 determines how "forgiving" the system is before it shuts down due to inadequate flow.
5.	To test sensitivity and operation, turn off the water at the source or the solution at the discharge. The float in the flow meter will fall more for the control knob setting described in step 41) than, for 4a (above).		As the source or discharge is turned off, the float in the flow meter falls and the pump is disabled.
6.	Set the rotameter for the desired flow.		Retest (as in step 5).

REM-1E Digital Display Pump Controller

Product Sheet


SIEMENS

The REM-1E Digital Display Controller serves as either a pump remote control station or a proportional pump controller (4-20 mA input) or both. The REM-1E can be used to vary the output of any Liquid Metronics (LMI) Series AA7, A7, B7, or C7 metering pump when those pumps are placed in the external mode. This is truly a "plug-n-play" accessory. A simple connection of 4-conductor cable from the control unit to the external input jack of the LMI pump is all that is required for start-up. Power is supplied by a 15 VDC source from the LMI pump through the 4-conductor cable.

The controller output, in the form of contact closures of 80 ms duration, triggers the LMI pump. In the internal mode, output is 0-100 strokes-per-hour (sph) or 0-100 strokes-per-minute (spm). A touch of the pressure-sensitive keys varies the


output, which is displayed in large, easy-to-read LCD digital format. Changes left for longer than 5 seconds are saved in non-volatile memory. In the external mode, output is from 0-100 sph or 0-100 spm directly proportional to the 4-20 mA analog input signal. Ten feet of 3-conductor cable and connectors are supplied as standard for the 4-20 mA application. Zero and span adjustments may be done through the outside keys of the controller.

In the "OFF" position, the 15 VDC power source will be present, but the controller output will be zero. The display will read OFF. The rugged, polycarbonate NEMA 4X enclosure is easily wall-mounted near the associated pump, or can be remotely located, using standard cable/connector sets available from Siemens.



The REM-1E Digital Display Pump Controller Offers:


- Accurate Solid-State Microprocessor Core Technology
- Easy to Program Push-Button Control
- Multiple Control Options
- Durable, NEMA 4X Enclosure



PART NOS.

RM1974183	CABLE
2723001	3 PIN CONNECTOR
25643	4 PIN CONNECTOR

NOTE: J-301 PIN NUMBERS CORRESPOND TO IDENTICAL PIN NUMBERS ON LMI PUMP REMOTE SIGNAL INPUT CONNECTORS.



CONNECTIONS INSIDE REM-1E

+V	WHITE
GND	BLACK
TRIG	GREEN
+V	RED
OUT	BLACK
SHIELD	GREEN
4-20 IN	RED

J-301, J-302 CONNECTORS

J-301, Pin #1
J-301, Pin #3
J-301, Pin #2
J-301, Pin #4
J-302, Pin #2
J-302, Pin #1
J-302, Pin #3

CABLE CONNECTIONS

RED	Future Use	4-Pin Connector J-301
WHITE	Power - (Common)	
GREEN	Pump Trigger (+15VDC)	
BLACK	Power + (+15VDC)	
BLACK	Signal Common	3-Pin Connector J-302 External Control 4-20mA DC 220Ω Input Impedance
WHITE	Shield (mech. ground)	
RED	4-20 mA Signal	

ZERO AND SPAN ADJUSTMENTS

1. Press MODE key to enter the off mode.
2. Pump output will stop. With OFF shown in the display, press and hold the MODE button until the display shows 'SPn'.
3. After three seconds, the upper span limit will be displayed. The default is 100 SPM, (and the maximum allowed if connected to an LMI metering pump).
4. Increase or decrease the upper limit by using the arrow keys.
5. Press MODE to accept the new value and advance to the minimum span limit adjustment.
6. The minimum span limit and default is 0. Use the arrow keys to change the lower span limit.
7. Then press MODE to continue to the CAL section and follow instructions at right starting at #3, or press MODE twice to return to the OFF mode.

CALIBRATION

1. From the OFF mode press and hold the MODE button until the display changes to 'SPn', then to the upper span limit.
2. Press MODE twice until the display shows CAL.
3. Press one of the arrow keys ▲ or ▼ (pressing MODE will skip the CAL sequence).
4. Display shows C4. (Calibration - 4mA)
5. Adjust input to a stable 4.00 mA signal for at least 10 seconds, then push both arrow ▲ ▼ buttons. 'ERR' means input is not near 4mA.
6. Display will change to C20.
7. Adjust input to 20.00 mA signal for at least 10 seconds, then push both arrow ▲ ▼ buttons.
8. After the calibration sequence is completed (or skipped), the display on the REM-1E will return to OFF.

* NOTE: GASKET KIT P/N K7809901 AVAILABLE FOR PANEL MOUNTING.

The information provided in this brochure contains merely general descriptions or characteristics of performance which in case of actual use do not always apply as described or which may change as a result of further development of the products. An obligation to provide the respective characteristics shall only exist if expressly agreed in terms of the contract.

Siemens
Water Technologies
595 Industrial Drive
Bradley, IL 60915, USA
www.usfilter.com
stranco.water@siemens.com

Literature No. ST-REM1E-DS-0606
815.929.4101 tel.
Bradley, IL 60915
Subject to change without notice.
©2006 Siemens Water Technologies Corp.

DIAPHRAGM PUMP INFORMATION

WARNING: ALWAYS wear protective clothing, face shield, safety glasses and gloves when working near or performing and maintenance or replacement on your pump. See MSDS Sheet from polymer supplier for additional precautions.

OUTPUT ADJUSTMENT CONTROLS

In most external controlled pumps the uppermost knob serves as speed control. Graduations for the Speed Knob appear directly on the face of the control panel. The largest knob below is Stroke Control.

1. Speed adjustment: Speed control provides adjustment of the percent of maximum strokes per minute. Turning this clockwise increase stroke frequency. **Note AA7 Series Only:** When operating pump in the external mode, the speed control knob should be fully turned counter clockwise. A click indicates pump is in external mode.

2. Stroke Adjustment; Stroke control provides adjustment of percent of maximum Liquifram (diaphragm) travel. Turning this knob counterclockwise increases percent output per stroke. Only adjust while pump is running.

PRIMING THE PUMP

Hold tip of syringe firmly in fitting with one hand while using the other hand to pull back on plunger. Repeat until a small amount of polymer is drawn into the syringe. The pump is now primed.

PUMP CALIBRATION

Perform calibration if your system application requires it. Normally calibration is NOT required.

You will need:

- A watch
- A calculator
- Calibrated cylinder (with at least 1000 ml capacity).

- Length of hose or tubing (same I.D. as pump ports)

1. Maintain all usual connections to the PolyBlend unit except disconnect the polymer suction line at pump input. The flow meter and pump setting should be those used for normal service.

2. Connect hose or tubing to the pump input. Place the free end of the tubing in the graduated cylinder.

3. Fill the cylinder with polymer to its measured capacity (for example, 1000 ml etc.).

4. Turn on the metering pump. Allow the pump to run until all air has been exhausted from the tubing and pump and polymer is injected into the mixing chamber.

5. Stop the pump.

6. Refill the cylinder to the measured capacity.

7. Start the pump again, and start timing as the pump runs. For best results, let the pump run long enough to pump at least half of the polymer out of the graduated cylinder. (in general, the longer the calibration period, the greater the accuracy of the measurement).

8. Stop the pump. Record the time and level of the polymer remaining in the cylinder. Fill in the following equation to find the volume of polymer pumped per one unit of time (a minute, an hour, or a day).

$$\frac{\text{Starting ml} - \text{Remaining ml}}{\text{Calibration period}} = \text{ml/Time}$$

9. Compare the actual volume pumped to the desired volume, and adjust pump controls.

10. Check volume again to confirm the new settings.

PRESSURE CONTROL (B and C series only)

A capped potentiometer is located on the face plate of the diaphragm pump. This potentiometer is for pressure control or power to the pump solenoid. Since the PolyBlend unit is equipped with a 20 PSI backpressure/check valve, the potentiometer should be set for full power or full clockwise.

NOTE: This is preset at the factory. In a case where obvious over-pumping is present, this potentiometer may be adjusted counter-clockwise.

Liquifram (Diaphragm) Replacement

When replacing the Liquifram, valve balls, seal rings and the injection check valve spring should also be replaced.

1. Carefully depressurize, drain and disconnect the pump discharge and suction lines. Place the suction tubing into a container of mineral oil. Turn the pump on to flush the head assembly. Once the pump head has been flushed, lift the suction tubing out of the mineral oil and continue to pump air into the pump head until the pump head is purged.


2. Start the pump. While running, set the stroke knob to zero and turn the pump off.

NOTE: See section on proper zeroing.

3. With the unit off, unscrew the Liquifram by carefully grasping the outer edge of the Liquifram and turning it counter clockwise. Discard old Liquifram disk if so equipped (locate behind the Liquifram) and check that the size code matches the size code on the replacement Liquifram (see illustration).

4. Reinstall the disk so alignment pin on the disk (if present) seats in the recessed hole in the EPU.

WARNING: Take care not to scratch the Teflon face of the new Liquifram.




5. Start the pump and turn the stroke knob to the setting indicated on the Stroke Setting Chart which matches the pump model number located on the pump dataplate. With the pump stoking (running), screw on the new Liquifram clockwise until the center begins to buckle inward. Stop the pump.

Liquifram Stroke Setting Chart

<u>Pump Series</u>	<u>Stroke Knob Settings</u>
A11 AA, B72, C72,	90%
C77	70%

6. Grasp the outer edge of the Liquifram and adjust by screwing it in or out so that the center of the Liquifram is flush with the outside of the spacer edge (see illustration).



7. Once the Liquifram is properly positioned, remount the pump head to the spacer using the four (4) screws. Tighten in a crisscross pattern. After one week of operation, recheck the screws and tighten if necessary.

Seal Ring, Ball and Injection Check Valve Spring Replacement

1. Carefully depressurize, drain and disconnect the discharge and suction lines. Place the suction tubing into a container of mineral oil. Turn the pump on to flush the head assembly. After flushing, lift the suction tubing out of the mineral oil and continue to pump air into the pump head until the pump head is purged. If the liquid cannot be pumped due to Liquifram rupture, with protective gloves, carefully disconnect the tubing and four screws to remove the head. Immerse the head in mineral oil or other neutralizing solution.

IMPORTANT: Before disassembling valves, note the orientation of seal ring and ball. (See illustration).


2. Carefully disconnect one tubing connection and fitting at a time and remove the worn seal ring and ball. Carefully loosen sealing by prying side to side using a small screw driver through the center hole of the seal ring.

3. Install new seal ring and ball in each location.

IMPORTANT: Note correct orientation.

4. Install the new spring valve in the Injection Check Valve.

Seal Ring, Ball and Injection Check Valve Spring Replacement



Order of Installation

Check Pump for Proper Zeroing (Stroke Knob)

1. With pump running, turn stroke knob counter clockwise toward zero or end of black or red band.

2. LISTEN to the clicking as the pump is running. The pump should operate quietly at the zero position (no clicking).

3. If the pump continues to click at zero or stops clicking before zero is reached, the pump must be reset.


Type I – Push on Knob **Rezeroing and Stroke Knob Disassembly and Assembly**


1. Remove stroke knob from the pump by grasping the knob firmly and pulling it toward you.
2. Pry off the yellow cap.
3. Place the knob on a flat surface.
4. Using needle nose pliers, squeeze the inner section up together while lifting the outer section up.
5. Push the inner section back onto the “D” shaped stroke shaft.
6. With the pump running, zero the pump by turning the inner section of the knob counter clockwise until the pump stops clicking.
7. Position the outer section of the knob so that the pointer aligns with zero on the nameplate or end of the black or red band.
8. Push down on the outer section (a snap sound indicates parts are locked together).
9. Replace the yellow cap over the outer section of the knob, aligning the tabs on the cap with the slots inside the knob.

Type III Collet Knob **Rezeroing and Stroke Knob Disassembly and Assembly**

1. Remove yellow cap.
2. Hold knob with soft jaw pliers.
3. Disconnect knob by loosening 5/16” (8mm) collet nut. There is no need to remove nut.
4. Remove knob by pulling towards you.
5. With pump running, zero the pump using a screwdriver to turn the stroke shaft counter-clockwise until the pump just stops clicking.
6. Pump is now zeroed.
7. Position knob at zero, or the end of the low range band, and tighten 5/16” (8mm) collet nut.
8. Replace yellow cap.

Stroke Knob Assembly (Type I)





**Integral Horsepower
AC Induction Motors
ODP, WPI, WP II Enclosure
TEFC Enclosure
Explosion Proof**

Installation & Operating Manual

Table of Contents

Section 1

General Information	1-1
Overview	1-1
Limited Warranty	1-1
Safety Notice	1-2
Receiving	1-4
Storage	1-4
Unpacking	1-4
Handling	1-4

Section 2

Installation & Operation	2-1
Overview	2-1
Location	2-1
Mounting	2-1
Alignment	2-1
Doweling & Bolting	2-2
Power Connection	2-2
Conduit Box	2-2
AC Power	2-2
First Time Start Up	2-4
Coupled Start Up	2-4
Jogging and Repeated Starts	2-4

Section 3

Maintenance & Troubleshooting	3-1
General Inspection	3-1
Lubrication & Bearings	3-1
Type of Grease	3-1
Lubrication Intervals	3-1
Lubrication Procedure	3-3
Accessories	3-4
Troubleshooting Chart	3-5

Section 1

General Information

Overview

This manual contains general procedures that apply to Baldor Motor products. Be sure to read and understand the Safety Notice statements in this manual. For your protection, do not install, operate or attempt to perform maintenance procedures until you understand the Warning and Caution statements. A Warning statement indicates a possible unsafe condition that can cause harm to personnel. A Caution statement indicates a condition that can cause damage to equipment.

Important:

This instruction manual is not intended to include a comprehensive listing of all details for all procedures required for installation, operation and maintenance. This manual describes general guidelines that apply to most of the motor products shipped by Baldor. If you have a question about a procedure or are uncertain about any detail, Do Not Proceed. Please contact your Baldor distributor for more information or clarification.

Before you install, operate or perform maintenance, become familiar with the following:

- NEMA Publication MG-2, Safety Standard for Construction and guide for Selection, Installation and Use of Electric Motors and Generators.
- The National Electrical Code
- Local codes and Practices

Limited Warranty

1. Most Baldor products are warranted for 18 months from the date of shipment to Baldor's customer from Baldor's district warehouse or, if applicable, from Baldor's factory. Baldor Standard-E® standard efficient motors are warranted for 24 months. Standard-E is limited to three phase, general purpose, 1–200 HP ratings that fall under the Energy Policy Act (EPA). Baldor Super-E® premium efficient motors are warranted for 36 months. Baldor IEEE841 motors are warranted for 60 months. All warranty claims must be submitted to a Baldor Service Center prior to the expiration of the warranty period.
2. Baldor will, at its option repair or replace a motor which fails due to defects in material or workmanship during the warranty period if:
 - a. the purchaser presents the defective motor at or ships it prepaid to, the Baldor plant in Fort Smith, Arkansas or one of the Baldor Authorized Service Centers and
 - b. the purchaser gives written notification concerning the motor and the claimed defect including the date purchased, the task performed by the Baldor motor and the problem encountered.
3. Baldor will not pay the cost of removal of any electric motor from any equipment, the cost of delivery to Fort Smith, Arkansas or a Baldor Authorized Service Center, or the cost of any incidental or consequential damages resulting from the claimed defects. (Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion may not apply to you.) Any implied warranty given by laws shall be limited to the duration of the warranty period hereunder. (Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.)
4. Baldor Authorized Service Centers, when convinced to their satisfaction that a Baldor motor developed defects in material or workmanship within the warranty period, are authorized to proceed with the required repairs to fulfill Baldor's warranty when the cost of such repairs to be paid by Baldor does not exceed Baldor's warranty repair allowance. Baldor will not pay overtime premium repair charges without prior written authorization.
5. The cost of warranty repairs made by centers other than Baldor Authorized Service Centers **WILL NOT** be paid unless first authorized in writing by Baldor.
6. Claims by a purchaser that a motor is defective even when a failure results within one hour after being placed into service are not always justified. Therefore, Baldor Authorized Service Centers must determine from the condition of the motor as delivered to the center whether or not the motor is defective. If in the opinion of a Baldor Authorized Service Center, a motor did not fail as a result of defects in material or workmanship, the center is to proceed with repairs only if the purchaser agrees to pay for such repairs. If the decision is in dispute, the purchaser should still pay for the repairs and submit the paid invoice and the Authorized Service Center's signed service report to Baldor for further consideration.
7. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Safety Notice:

This equipment contains high voltage! Electrical shock can cause serious or fatal injury. Only qualified personnel should attempt installation, operation and maintenance of electrical equipment.

Be sure that you are completely familiar with NEMA publication MG-2, safety standards for construction and guide for selection, installation and use of electric motors and generators, the National Electrical Code and local codes and practices. Unsafe installation or use can cause conditions that lead to serious or fatal injury. Only qualified personnel should attempt the installation, operation and maintenance of this equipment.

- WARNING:** Do not touch electrical connections before you first ensure that power has been disconnected. Electrical shock can cause serious or fatal injury. Only qualified personnel should attempt the installation, operation and maintenance of this equipment.
- WARNING:** Be sure the system is properly grounded before applying power. Do not apply AC power before you ensure that all grounding instructions have been followed. Electrical shock can cause serious or fatal injury. National Electrical Code and Local codes must be carefully followed.
- WARNING:** Avoid extended exposure to machinery with high noise levels. Be sure to wear ear protective devices to reduce harmful effects to your hearing.
- WARNING:** This equipment may be connected to other machinery that has rotating parts or parts that are driven by this equipment. Improper use can cause serious or fatal injury. Only qualified personnel should attempt to install operate or maintain this equipment.
- WARNING:** Do not by-pass or disable protective devices or safety guards. Safety features are designed to prevent damage to personnel or equipment. These devices can only provide protection if they remain operative.
- WARNING:** Avoid the use of automatic reset devices if the automatic restarting of equipment can be hazardous to personnel or equipment.
- WARNING:** Be sure the load is properly coupled to the motor shaft before applying power. The shaft key must be fully captive by the load device. Improper coupling can cause harm to personnel or equipment if the load decouples from the shaft during operation.
- WARNING:** Use proper care and procedures that are safe during handling, lifting, installing, operating and maintaining operations. Improper methods may cause muscle strain or other harm.
- WARNING:** Before performing any motor maintenance procedure, be sure that the equipment connected to the motor shaft cannot cause shaft rotation. If the load can cause shaft rotation, disconnect the load from the motor shaft before maintenance is performed. Unexpected mechanical rotation of the motor parts can cause injury or motor damage.
- WARNING:** Disconnect all electrical power from the motor windings and accessory devices before disassembly of the motor. Electrical shock can cause serious or fatal injury.
- WARNING:** Do not use non UL/CSA listed explosion proof motors in the presence of flammable or combustible vapors or dust. These motors are not designed for atmospheric conditions that require explosion proof operation.
-

Safety Notice Continued

- WARNING:** Motors that are to be used in flammable and/or explosive atmospheres must display the UL label on the nameplate along with CSA listed logo.
- Specific service conditions for these motors are defined in NFPA 70 (NEC) Article 500.
- WARNING:** UL rated motors must only be serviced by authorized Baldor Service Centers if these motors are to be returned to a flammable and/or explosive atmosphere.
- Caution:** To prevent premature equipment failure or damage, only qualified maintenance personnel should perform maintenance.
- Caution:** Do not lift the motor and its driven load by the motor lifting hardware. The motor lifting hardware is adequate for lifting only the motor. Disconnect the load from the motor shaft before moving the motor.
- Caution:** If eye bolts are used for lifting a motor, be sure they are securely tightened. The lifting direction should not exceed a 20° angle from the shank of the eye bolt or lifting lug. Excessive lifting angles can cause damage.
- Caution:** To prevent equipment damage, be sure that the electrical service is not capable of delivering more than the maximum motor rated amps listed on the rating plate.
- Caution:** If a HI POT test (High Potential Insulation test) must be performed, follow the precautions and procedure in NEMA MG-1 and MG-2 standards to avoid equipment damage.

If you have any questions or are uncertain about any statement or procedure, or if you require additional information please contact your Baldor distributor or an Authorized Baldor Service Center.

Receiving

Each Baldor Electric Motor is thoroughly tested at the factory and carefully packaged for shipment. When you receive your motor, there are several things you should do immediately.

1. Observe the condition of the shipping container and report any damage immediately to the commercial carrier that delivered your motor.
2. Verify that the part number of the motor you received is the same as the part number listed on your purchase order.

Storage

If the motor is not put into service immediately, the motor must be stored in a clean, dry and warm location. Several precautionary steps must be performed to avoid motor damage during storage.

1. Use a "Megger" periodically to ensure that the integrity of the winding insulation has been maintained. Record the Megger readings. Immediately investigate any significant drop in insulation resistance.
2. Do not lubricate bearings during storage. Motor bearings are packed with grease at the factory. Excessive grease can damage insulation quality.
3. Rotate motor shaft at least 10 turns every two months during storage (more frequently if possible). This will prevent bearing damage due to storage.
4. If the storage location is damp or humid, the motor windings must be protected from moisture. This can be done by applying power to the motors' space heater (if available) while the motor is in storage.

Unpacking

Each Baldor motor is packaged for ease of handling and to prevent entry of contaminants.

1. To avoid condensation inside the motor, do not unpack until the motor has reached room temperature. (Room temperature is the temperature of the room in which it will be installed). The packing provides insulation from temperature changes during transportation.
2. When the motor has reached room temperature, remove all protective wrapping material from the motor.

Handling

The motor should be lifted using the lifting lugs or eye bolts provided.

1. Use the lugs or eye bolts provided to lift the motor. Never attempt to lift the motor and additional equipment connected to the motor by this method. The lugs or eye bolts provided are designed to lift only the motor. Never lift the motor by the motor shaft or the hood of a WP11 motor.
2. When lifting a WP11 (weatherproof Type 2) motor, do not lift the motor by inserting lifting lugs into holes on top of the cooling hood. These lugs are to be used for hood removal only. A spreader bar should be used to lift the motor by the cast lifting lugs located on the motor frame.
3. If the motor must be mounted to a plate with the driven equipment such as pump, compressor etc., it may not be possible to lift the motor alone. For this case, the assembly should be lifted by a sling around the mounting base. The entire assembly can be lifted as an assembly for installation. Do not lift using the motor lugs or eye bolts provided.

If the load is unbalanced (as with couplings or additional attachments) additional slings or other means must be used to prevent tipping. In any event, the load must be secure before lifting.

Section 2

Installation & Operation

Overview

Installation should conform to the National Electrical Code as well as local codes and practices. When other devices are coupled to the motor shaft, be sure to install protective devices to prevent future accidents. Some protective devices include, coupling, belt guard, chain guard, shaft covers etc. These protect against accidental contact with moving parts. Machinery that is accessible to personnel should provide further protection in the form of guard rails, screening, warning signs etc.

Location

It is important that motors be installed in locations that are compatible with motor enclosure and ambient conditions. Improper selection of the motor enclosure and ambient conditions can lead to reduced operating life of the motor.

Proper ventilation for the motor must be provided. Obstructed airflow can lead to reduction of motor life.

1. **Open Drip-proof/WPI** motors are intended for use indoors where atmosphere is relatively clean, dry, well ventilated and non-corrosive.
2. **Totally Enclosed and WPII** motors may be installed where dirt, moisture or dust are present and in outdoor locations.

Chemical Duty enclosed motors are designed for installations with high corrosion or excessive moisture conditions. These motors should not be placed into an environment where there is the presence of flammable or combustible vapors, dust or any combustible material, unless specifically designed for this type of service.

Mounting

The motor must be securely installed to a rigid foundation or mounting surface to minimize vibration and maintain alignment between the motor and shaft load. Failure to provide a proper mounting surface may cause vibration, misalignment and bearing damage.

Foundation caps and sole plates are designed to act as spacers for the equipment they support. If these devices are used, be sure that they are evenly supported by the foundation or mounting surface.

After installation is complete and accurate alignment of the motor and load is accomplished, the base should be grouted to the foundation to maintain this alignment.

The standard motor base is designed for horizontal or vertical mounting. Adjustable or sliding rails are designed for horizontal mounting only. Consult your Baldor distributor or authorized Baldor Service Center for further information.

Alignment

Accurate alignment of the motor with the driven equipment is extremely important.

1. **Direct Coupling**

For direct drive, use flexible couplings if possible. Consult the drive or equipment manufacturer for more information. Mechanical vibration and roughness during operation may indicate poor alignment. Use dial indicators to check alignment. The space between coupling hubs should be maintained as recommended by the coupling manufacturer.

2. **End-Play Adjustment**

The axial position of the motor frame with respect to its load is also extremely important. The motor bearings are not designed for excessive external axial thrust loads. Improper adjustment will cause failure.

3. **Pulley Ratio**

The pulley ratio should not exceed 8:1.

4. **Belt Drive**

Align sheaves carefully to minimize belt wear and axial bearing loads (see End-Play Adjustment). Belt tension should be sufficient to prevent belt slippage at rated speed and load. However, belt slippage may occur during starting.

Caution: Do not over tension belts.

5. Sleeve bearing motors are only suitable for coupled loads.

Doweling & Bolting

After proper alignment is verified, dowel pins should be inserted through the motor feet into the foundation. This will maintain the correct motor position should motor removal be required. (Baldor motors are designed for doweling.)

1. Drill dowel holes in diagonally opposite motor feet in the locations provided.
2. Drill corresponding holes in the foundation.
3. Ream all holes.
4. Install proper fitting dowels.
5. Mounting bolts must be carefully tightened to prevent changes in alignment. Use a flat washer and lock washer under each nut or bolt head to hold the motor feet secure. Flanged nuts or bolts may be used as an alternative to washers.

Power Connection

Conduit Box

Motor and control wiring, overload protection, disconnects, accessories and grounding should conform to the National Electrical Code and local codes and practices.

For ease of making connections, an oversize conduit box is provided. The box can be rotated 360° in 90° increments. Auxiliary conduit boxes are provided on some motors for accessories such as space heaters, RTD's etc.


AC Power

Connect the motor leads as shown on the connection diagram located on the name plate or inside the cover on the conduit box. Be sure the following guidelines are met:

1. AC power is within $\pm 10\%$ of rated voltage with rated frequency. (See motor name plate for ratings).
OR
2. AC power is within $\pm 5\%$ of rated frequency with rated voltage.
OR
3. A combined variation in voltage and frequency of $\pm 10\%$ (sum of absolute values) of rated values, provided the frequency variation does not exceed $\pm 5\%$ of rated frequency.

Performance within these voltage and frequency variations are shown in Figure 2-1.

Figure 2-1 Typical Motor Performance VS Voltage Variations



First Time Start Up

Be sure that all power to motor and accessories is off. Be sure the motor shaft is disconnected from the load and will not cause mechanical rotation of the motor shaft.

1. Make sure that the mechanical installation is secure. All bolts and nuts are tightened etc.
2. If motor has been in storage or idle for some time, check winding insulation integrity with a Megger.
3. Inspect all electrical connections for proper termination, clearance, mechanical strength and electrical continuity.
4. Be sure all shipping materials and braces (if used) are removed from motor shaft.
5. Manually rotate the motor shaft to ensure that it rotates freely.
6. Replace all panels and covers that were removed during installation.
7. Momentarily apply power and check the direction of rotation of the motor shaft.
8. If motor rotation is wrong, be sure power is off and change the motor lead connections. Verify rotation direction before you continue.
9. Start the motor and ensure operation is smooth without excessive vibration or noise. If so, run the motor for 1 hour with no load connected.
10. After 1 hour of operation, disconnect power and connect the load to the motor shaft. Verify all coupling guards and protective devices are installed. Ensure motor is properly ventilated.

Coupled Start Up

This procedure assumes a coupled start up. Also, that the first time start up procedure was successful.

1. Check the coupling and ensure that all guards and protective devices are installed.
2. Check that the coupling is properly aligned and not binding.
3. The first coupled start up should be with no load. Apply power and verify that the load is not transmitting excessive vibration back to the motor through the coupling or the foundation. Vibration should be at an acceptable level.
4. Run for approximately 1 hour with the driven equipment in an unloaded condition.

The equipment can now be loaded and operated within specified limits. Do not exceed the name plate ratings for amperes for steady continuous loads.

Jogging and Repeated Starts Repeated starts and/or jogs of induction motors generally reduce the life of the motor winding insulation. A much greater amount of heat is produced by each acceleration or jog than by the same motor under full load. If it is necessary to repeatedly start or jog the motor, it is advisable to check the application with your local Baldor distributor or Baldor Service Center.

Heating - Duty rating and maximum ambient temperature are stated on the motor name plate. Do not exceed these values. If there is any question regarding safe operation, contact your local Baldor distributor or Baldor Service Center.

Section 3

Maintenance & Troubleshooting

WARNING: UL rated motors must only be serviced by authorized Baldor Service Centers if these motors are to be returned to a flammable and/or explosive atmosphere.

General Inspection

Inspect the motor at regular intervals, approximately every 500 hours of operation or every 3 months, whichever occurs first. Keep the motor clean and the ventilation openings clear. The following steps should be performed at each inspection:

WARNING: Do not touch electrical connections before you first ensure that power has been disconnected. Electrical shock can cause serious or fatal injury. Only qualified personnel should attempt the installation, operation and maintenance of this equipment.

1. Check that the motor is clean. Check that the interior and exterior of the motor is free of dirt, oil, grease, water, etc. Oily vapor, paper pulp, textile lint, etc. can accumulate and block motor ventilation. If the motor is not properly ventilated, overheating can occur and cause early motor failure.
2. Use a "Megger" periodically to ensure that the integrity of the winding insulation has been maintained. Record the Megger readings. Immediately investigate any significant drop in insulation resistance.
3. Check all electrical connectors to be sure that they are tight.

Lubrication & Bearings

Bearing grease will lose its lubricating ability over time, not suddenly. The lubricating ability of a grease (over time) depends primarily on the type of grease, the size of the bearing, the speed at which the bearing operates and the severity of the operating conditions. Good results can be obtained if the following recommendations are used in your maintenance program.

Type of Grease

A high grade ball or roller bearing grease should be used. Recommended grease for standard service conditions is Polyrex EM (Exxon Mobil).

Equivalent and compatible greases include:

Texaco Polystar, Rykon Premium #2, Pennzoil Pen 2 Lube and Chevron SRI.

– Maximum operating temperature for standard motors = 110° C.

– Shut-down temperature in case of a malfunction = 115° C.

Lubrication Intervals

Recommended lubrication intervals are shown in Table 3-1. It is important to realize that the recommended intervals of Table 3-1 are based on average use.

Refer to additional information contained in Tables 3-2 and 3-3.

Table 3-1 Lubrication Intervals *

NEMA / (IEC) Frame Size	Rated Speed - RPM					
	10000	6000	3600	1800	1200	900
Up to 210 incl. (132)	**	2700 Hrs.	5500 Hrs.	12000 Hrs.	18000 Hrs.	22000 Hrs.
Over 210 to 280 incl. (180)		**	3600 Hrs.	9500 Hrs.	15000 Hrs.	18000 Hrs.
Over 280 to 360 incl. (225)			* 2200 Hrs.	7400 Hrs.	12000 Hrs.	15000 Hrs.
Over 360 to 5800 incl. (300)			*2200 Hrs.	3500 Hrs.	7400 Hrs.	10500 Hrs.

* Lubrication intervals are for ball bearings. For vertically mounted motors and roller bearings, divide the lubrication interval by 2.

** For motors operating in this speed range, contact Baldor for lubrication recommendations based on specific motor and application.

Table 3-2 Service Conditions

Severity of Service	Hours per day of Operation	Ambient Temperature Maximum	Atmospheric Contamination
Standard	8	40° C	Clean, Little Corrosion
Severe	16 Plus	50° C	Moderate dirt, Corrosion
Extreme	16 Plus	>50° C* or Class H Insulation	Severe dirt, Abrasive dust, Corrosion, Heavy Shock or Vibration
Low Temperature		<-30° C **	

* Special high temperature grease is recommended (Dow Corning DC44). Note that Dow Corning DC44 grease does not mix with other grease types. Thoroughly clean bearing & cavity before adding grease.

** Special low temperature grease is recommended (Aeroshell 7).

Table 3-3 Lubrication Interval Multiplier

Severity of Service	Multiplier
Standard	1.0
Severe	0.5
Extreme	0.1
Low Temperature	1.0

Table 3-4 Bearings Sizes and Types

Frame Size NEMA (IEC)	Bearing Description (These are the "Large" bearings (Shaft End) in each frame size)					
	Bearing	OD D mm	Width B mm	Weight of Grease to add * oz (Grams)	Volume of grease to be added	
					in ³	tea- spoon
56 to 180 incl. (63 to 112)	6206	62	16	0.19 (5.0)	0.3	1.0
210 incl. (132)	6307	80	21	0.30 (8.4)	0.6	2.0
Over 210 to 280 incl. (180)	6311	120	29	0.61 (17)	1.2	3.9
Over 280 to 360 incl. (225)	6313	140	33	0.81 (23)	1.5	5.2
Over 360 to 449 incl. (280)	6319	200	45	2.12 (60)	4.1	13.4
Over 5000 to 5800 incl. (355)	6328	300	62	4.70 (130)	9.2	30.0
Over 360 to 449 incl. (280)	NU319	200	45	2.12 (60)	4.1	13.4
Over 5000 to 5800 incl. (355)	NU328	300	62	4.70 (130)	9.2	30.0
Spindle Motors						
76 Frame	6207	72	17	0.22 (6.1)	0.44	1.4
77 Frame	6210	90	20	0.32 (9.0)	0.64	2.1
80 Frame	6213	120	23	0.49 (14.0)	0.99	3.3

* Weight in grams = .005 DB

Note: Not all bearing sizes are listed. For intermediate bearing sizes, use the grease volume for the next larger size bearing.

Lubrication Procedure

Be sure that the grease you are adding to the motor is compatible with the grease already in the motor. Consult your Baldor distributor or an authorized service center if a grease other than the recommended type is to be used.

Caution: To avoid damage to motor bearings, grease must be kept free of dirt. For an extremely dirty environment, contact your Baldor distributor or an authorized Baldor Service Center for additional information.

With Grease Outlet Plug

1. With the motor stopped, clean all grease fittings.
2. Remove grease outlet plug.

Caution: Overgreasing can cause excessive bearing temperatures, premature lubrication breakdown and bearing failure.

3. Add the recommended amount of grease.
4. Operate the motor for 15 minutes with grease plug removed. This allows excess grease to purge.
5. Re-install grease outlet plug.

Without Grease Provisions

Note: Only a Baldor authorized and UL or CSA certified service center can disassemble a UL/CSA listed explosion proof motor to maintain its UL/CSA listing.

1. Disassemble the motor.
2. Add recommended amount of grease to bearing and bearing cavity. (Bearing should be about 1/3 full of grease and outboard bearing cavity should be about 1/2 full of grease.)
3. Assemble the motor.

Sample Lubrication Determination

Assume - NEMA 256T (IEC 180), 1750 RPM motor driving an exhaust fan in an ambient temperature of 43° C and the atmosphere is moderately corrosive.

1. Table 3-1 list 9500 hours for standard conditions.
2. Table 3-2 classifies severity of service as "Severe".
3. Table 3-3 lists a multiplier value of 0.5 for Severe conditions.
4. Table 3-4 shows that 1.2 in³ or 3.9 teaspoon of grease is to be added.

Note: Smaller bearings in size category may require reduced amounts of grease.

Accessories

The following is a partial list of accessories available from Baldor.
Contact your Baldor distributor for availability and pricing information.

Note: Space heaters and RTD's are standard on some motors.

Bearing RTD

RTD (Resistance Temperature Detector) devices are used to measure or monitor the temperature of the motor bearing during operation.

Bearing Thermocouples

Used to measure or monitor bearing temperatures.

Bearing Thermostat

Temperature device that activates when bearing temperatures are excessive.
Used with an external circuit to warn of excessive bearing temperature or to shut down a motor.

Conduit Boxes

Optional conduit boxes are available in various sizes to accommodate accessory devices.

Cord & Plug Assembly

Adds a line cord and plug for portable applications.

Drains and Breathers

Stainless steel drains with separate breathers are available.

Drip Covers

Designed for use when motor is mounted in a vertical position. Contact your Baldor distributor to confirm that the motor is designed for vertical mounting.

Fan Cover & Lint Screen

To prevent build-up of debris on the cooling fan.

Nameplate

Additional stainless steel nameplates are available.

Roller Bearings

Recommended for belt drive applications with a speed of 1800 RPM or less.

Rotation Arrow Labels

Rotation arrows are supplied on motors designed to operate in one direction only. Additional rotation arrows are available.

Space Heater

Added to prevent condensation of moisture within the motor enclosure during periods of shut down or storage.

Stainless Hardware

Stainless steel hardware is available. Standard hardware is corrosion resistant zinc plated steel.

Winding RTD

RTD (Resistance Temperature Detector) devices are used to measure or monitor the temperature of the motor winding during operation.

Winding Thermocouples

Used to measure or monitor winding temperatures.

Winding Thermostat

Temperature device that activates when winding temperatures are excessive.
Used with an external circuit to warn of excessive winding temperature or to shut down a motor.

Note: On some motors, leads for accessory devices are brought out to a separate conduit box located on the side of the motor housing (unless otherwise specified).

Table 3-5 Troubleshooting Chart

Symptom	Possible Causes	Possible Solutions
Motor will not start	Usually caused by line trouble, such as, single phasing at the starter.	Check source of power. Check overloads, fuses, controls, etc.
Excessive humming	High Voltage.	Check input line connections.
	Eccentric air gap.	Have motor serviced at local Baldor service center.
Motor Over Heating	Overload. Compare actual amps (measured) with nameplate rating.	Locate and remove source of excessive friction in motor or load. Reduce load or replace with motor of greater capacity.
	Single Phasing.	Check current at all phases (should be approximately equal) to isolate and correct the problem.
	Improper ventilation.	Check external cooling fan to be sure air is moving properly across cooling fins. Excessive dirt build-up on motor. Clean motor.
	Unbalanced voltage.	Check voltage at all phases (should be approximately equal) to isolate and correct the problem.
	Rotor rubbing on stator.	Check air gap clearance and bearings. Tighten "Thru Bolts".
	Over voltage or under voltage.	Check input voltage at each phase to motor.
	Open stator winding.	Check stator resistance at all three phases for balance.
	Grounded winding.	Perform dielectric test and repair as required.
	Improper connections.	Inspect all electrical connections for proper termination, clearance, mechanical strength and electrical continuity. Refer to motor lead connection diagram.
Bearing Over Heating	Misalignment.	Check and align motor and driven equipment.
	Excessive belt tension.	Reduce belt tension to proper point for load.
	Excessive end thrust.	Reduce the end thrust from driven machine.
	Excessive grease in bearing.	Remove grease until cavity is approximately $\frac{3}{4}$ filled.
	Insufficient grease in bearing.	Add grease until cavity is approximately $\frac{3}{4}$ filled.
	Dirt in bearing.	Clean bearing cavity and bearing. Repack with correct grease until cavity is approximately $\frac{3}{4}$ filled.
Vibration	Misalignment.	Check and align motor and driven equipment.
	Rubbing between rotating parts and stationary parts.	Isolate and eliminate cause of rubbing.
	Rotor out of balance.	Have rotor balance checked and repaired at your Baldor Service Center.
	Resonance.	Tune system or contact your Baldor Service Center for assistance.
Noise	Foreign material in air gap or ventilation openings.	Remove rotor and foreign material. Reinstall rotor. Check insulation integrity. Clean ventilation openings.
Growling or whining	Bad bearing.	Replace bearing. Clean all grease from cavity and new bearing. Repack with correct grease until cavity is approximately $\frac{3}{4}$ filled.

Suggested bearing and winding RTD setting guidelines

Most large frame AC Baldor motors with a 1.15 service factor are designed to operate below a Class B (80°C) temperature rise at rated load and are built with a Class H winding insulation system. Based on this low temperature rise, RTD (Resistance Temperature Detectors) settings for Class B rise should be used as a starting point. Some motors with 1.0 service factor have Class F temperature rise.

The following tables show the suggested alarm and trip settings for RTDs. Proper bearing and winding RTD alarm and trip settings should be selected based on these tables unless otherwise specified for specific applications.

If the driven load is found to operate well below the initial temperature settings under normal conditions, the alarm and trip settings may be reduced so that an abnormal machine load will be identified.

The temperature limits are based on the installation of the winding RTDs imbedded in the winding as specified by NEMA. Bearing RTDs should be installed so they are in contact with the outer race on ball or roller bearings or in direct contact with the sleeve bearing shell.

Winding RTDs – Temperature Limit In °C (40°C Maximum Ambient)

Motor Load	Class B Temp Rise ≤ 80°C (Typical Design)		Class F Temp Rise ≤ 105°C		Class H Temp Rise ≤ 125°C	
	Alarm	Trip	Alarm	Trip	Alarm	Trip
≤ Rated Load	130	140	155	165	175	185
Rated Load to 1.15 S.F.	140	150	160	165	180	185

- Note:
- Winding RTDs are factory production installed, not from Mod-Express.
 - When Class H temperatures are used, consider bearing temperatures and lubrication requirements.

Bearing RTDs – Temperature Limit In °C with 40°C Max Ambient

Bearing Type Oil or Grease	Anti-Friction		Sleeve	
	Alarm	Trip	Alarm	Trip
Standard*	95	100	85	95
High Temperature**	110	115	105	110

- Note:
- * Bearing temperature limits are for standard design motors operating at Class B temperature rise.
 - ** High temperature lubricants include some special synthetic oils and greases.

Greases that may be substituted that are compatible with Polyrex EM (but considered as “standard” lubricants) include the following:

- Texaco Polystar
- Rykon Premium #2
- Chevron SRI #2

See the motor nameplate for replacement grease or oil recommendation. Contact Baldor application engineering for special lubricants or further clarifications.

Baldor District Offices

UNITED STATES

ARIZONA

PHOENIX
4211 S 43RD PLACE
PHOENIX, AZ 85040
PHONE: 602-470-0407
FAX: 602-470-0464

CALIFORNIA

LOS ANGELES
6480 FLOTILLA
COMMERCE, CA 90040
PHONE: 323-724-6771
FAX: 323-721-5859

HAYWARD
21056 FORBES STREET
HAYWARD, CA 94545
PHONE: 510-785-9900
FAX: 510-785-9910

COLORADO

DENVER
2520 W BARBERRY PLACE
DENVER, CO 80204
PHONE: 303-623-0127
FAX: 303-595-3772

CONNECTICUT

WALLINGFORD
65 SOUTH TURNPIKE ROAD
WALLINGFORD, CT 06492
PHONE: 203-269-1354
FAX: 203-269-5485

FLORIDA

TAMPA/PUERTO RICO/
VIRGIN ISLANDS
3906 EAST 11TH AVENUE
TAMPA, FL 33605
PHONE: 813-248-5078
FAX: 813-247-2984

GEORGIA

ATLANTA
62 TECHNOLOGY DR.
ALPHARETTA, GA 30005
PHONE: 770-772-7000
FAX: 770-772-7200

ILLINOIS

CHICAGO
1601 FRONTENAC ROAD
NAPERVILLE, IL 60563
PHONE: 630-848-5100
FAX: 630-848-5110

INDIANA

INDIANAPOLIS
5525 W. MINNESOTA STREET
INDIANAPOLIS, IN 46241
PHONE: 317-246-5100
FAX: 317-246-5110
800-428-4141

IOWA

DES MOINES
1800 DIXON STREET, SUITE C
DES MOINES, IA 50316
PHONE: 515-263-6929
FAX: 515-263-6515

MARYLAND

BALTIMORE
6660 SANTA BARBARA RD.
SUITE 22-24
ELKRIDGE, MD 21075
PHONE: 410-579-2135
FAX: 410-579-2677

MASSACHUSETTS

BOSTON
6 PULLMAN STREET
WORCESTER, MA 01606
PHONE: 508-854-0708
FAX: 508-854-0291

MICHIGAN

DETROIT
33782 STERLING PONDS BLVD.
STERLING HEIGHTS, MI 48312
PHONE: 586-978-9800

FAX: 586-978-9969

MICHIGAN Continued

GAND RAPIDS
668 3 MILE ROAD NW
GRAND RAPIDS, MI 49504
PHONE: 616-785-1784
FAX: 616-785-1788

MINNESOTA

MINNEAPOLIS
21080 134TH AVE. NORTH
ROGERS, MN 55374
PHONE: 763-428-3633
FAX: 763-428-4551

MISSOURI

ST LOUIS
422 INDUSTRIAL DRIVE
MARYLAND HEIGHTS, MO 63043
PHONE: 314-298-1800
FAX: 314-298-7660

KANSAS CITY

915 N W PLATTE VALLEY DR
RIVERSIDE, MO 64150
PHONE: 816-587-0272
FAX: 816-587-3735

NEW YORK

AUBURN
ONE ELLIS DRIVE
AUBURN, NY 13021
PHONE: 315-255-3403
FAX: 315-253-9923

NORTH CAROLINA

GREENSBORO
1220 ROTHERWOOD ROAD
GREENSBORO, NC 27406
P O BOX 16500
GREENSBORO, NC 27416
PHONE: 336-272-6104
FAX: 336-273-6628

OHIO

CINCINNATI
2929 CRESCENTVILLE ROAD
WEST CHESTER, OH 45069
PHONE: 513-771-2600
FAX: 513-772-2219

CLEVELAND

8929 FREEWAY DRIVE
MACEDONIA, OH 44056
PHONE: 330-468-4777
FAX: 330-468-4778

OKLAHOMA

TULSA
2 EAST DAWES
BIXBY, OK 74008
PHONE: 918-366-9320
FAX: 918-366-9338

OREGON

PORTLAND
20393 SW AVERY COURT
TUALATIN, OR 97062
PHONE: 503-691-9010
FAX: 503-691-9012

PENNSYLVANIA

PHILADELPHIA
1035 THOMAS BUSCH
MEMORIAL HIGHWAY
PENNSAUKEN, NJ 08110
PHONE: 856-661-1442
FAX: 856-663-6363

PITTSBURGH

616H BEATTY ROAD
MONROEVILLE, PA 15146
PHONE: 412-380-7244
FAX: 412-380-7250

TENNESSEE

MEMPHIS
4000 WINCHESTER ROAD
MEMPHIS, TN 38118
PHONE: 901-365-2020
FAX: 901-365-3914

TEXAS

HOUSTON
4647 PINE TIMBERS
SUITE # 135
HOUSTON, TX 77041
PHONE: 713-895-7062
FAX: 713-690-4540

DALLAS

3040 QUEBEC
DALLAS, TX 75247
PHONE: 214-634-7271
FAX: 214-634-8874

UTAH

SALT LAKE CITY
2230 SOUTH MAIN STREET
SALT LAKE CITY, UT 84115
PHONE: 801-832-0127
FAX: 801-832-8911

WISCONSIN

MILWAUKEE
2725 SOUTH 163RD STREET
NEW BERLIN, WI 53151
PHONE: 262-784-5940
FAX: 262-784-1215

INTERNATIONAL SALES

FORT SMITH, AR
P.O. BOX 2400
FORT SMITH, AR 72902
PHONE: 479-646-4711
FAX: 479-648-5895

CANADA

EDMONTON, ALBERTA
4053-92 STREET
EDMONTON, ALBERTA T6E 6R8
PHONE: 780-434-4900
FAX: 780-438-2600

OAKVILLE, ONTARIO

2750 COVENTRY ROAD
OAKVILLE, ONTARIO L6H 6R1
PHONE: 905-829-3301
FAX: 905-829-3302

MONTREAL, QUEBEC

1844 WILLIAM STREET
MONTREAL, QUEBEC H3J 1R5
PHONE: 514-933-2711
FAX: 514-933-8639

VANCOUVER,

BRITISH COLUMBIA
1538 KEBET WAY
PORT COQUITLAM, BC V3C 5M5
PHONE: 604-421-2822
FAX: 604-421-3113

WINNIPEG, MANITOBA

54 PRINCESS STREET
WINNIPEG, MANITOBA R3B 1K2
PHONE: 204-942-5205
FAX: 204-956-4251

AUSTRALIA

UNIT 3, 6 STANTON ROAD
SEVEN HILLS, NSW 2147,
AUSTRALIA
PHONE: (61) (2) 9674 5455
FAX: (61) (2) 9674 2495

UNIT 8, 5 KELLETTS ROAD

ROWVILLE, VICTORIA, 3178
AUSTRALIA
PHONE: (61) (3) 9753 4355
FAX: (61) (3) 9753 4366

BALDOR CENTROAMERICA

RESIDENCIAL PINARES DE SUIZA
POL. 15 #44, NVA. SAN SALVADOR
EL SALVADOR, CENTRO AMERICA
PHONE: (503) 288-1519
FAX: (503) 288-1518

BALDOR SUDAMERICA

CALLE F. EL CANGREJO
CONDOMINIO P.H. CONDADO PLAZA
APT. 11D, BELLA VISTA
PANAMÁ CITY, REP. DE PANAMÁ
PHONE: (507) 265-6041

CHINA

SHANGHAI JIAHUA BUSINESS CENTER
ROOM NO. A-8421
808 HONG QIAO ROAD
SHANGHAI 200030
PHONE: 86-21-64473060
FAX: 86-21-64078620

GERMANY

DIESELSTRASSE 22
D-85551 KIRCHHEIM
MUNICH, GERMANY
PHONE: (49) (89) 90508 - 0
FAX: (49) (89) 90508 - 492

INDIA

14, COMMERCE AVENUE
MAHAGANESH COLONY
PAUD ROAD
PUNE - 411 038
MAHARASHTRA, INDIA
PHONE: 91 20 25 45 95 31/32
FAX: 91 20 24 55 95 30

ITALY

BALDOR ASR AG
SUCCURSALE DI MENDRISIO
VIA BORROMINI, 20A
CH-6850 MENDRISIO
SWITZERLAND
PHONE: 41 91 640 9952
FAX: 41 91 630 2633

JAPAN

DIA BLDG 802,
2-21-1 TSURUYA-CHO,
KANAGAWA-KU
YOKOHAMA, 221-0835, JAPAN
PHONE: 81-45-412-4506
FAX: 81-45-412-4507

KOREA

ROOM 210
BUPYEONG INDUSTRIAL
COMMERCIAL COOPERATIVE
396-16 CHEONGCHEON 2-DONG,
BUPYEONG-GU
INCHEON, KOREA, 403-858
PHONE: 82 32 508 3252
FAX: 82 32 508 3253

MÉXICO

KM. 2.0 BLVD. AL AEROPUERTO
LEÓN 37545, GUANAJUATO, MÉXICO
PHONE: 52 477 761 2030
FAX: 52 477 761 2010

MIDDLE EAST & NORTH AFRICA

VSE INTERNATIONAL CORP.
3233 NORTH ARLINGTON HEIGHTS
SUITE 100W
ARLINGTON HEIGHTS, IL 60004
PHONE: 847 590 5547

SINGAPORE

51 KAKI BUKIT ROAD 2
K B WAREHOUSE COMPLEX
SINGAPORE 417863
PHONE: (65) 6 744 2572
FAX: (65) 6 747 1708

SWITZERLAND

POSTFACH 73
SCHUTZENSTRASSE 59
CH-8245 FEUERTHALEN
SWITZERLAND
PHONE: (41) (52) 6474700
FAX: (41) (52) 6592394

TAIWAN

4F, NO. 25, SEC. 1,
TUNHUA S ROAD,
TAIPEI 10557, TAIWAN, R.O.C.
PHONE: (886-2) 2577-4352
FAX: (886-2) 2577-4157

UNITED KINGDOM

6 BRISTOL DISTRIBUTION PARK
HAWKLEY DRIVE
BRISTOL BS32 0BF U.K.
PHONE: 44 1454 850000
FAX: 44 1454 859001



BALDOR ELECTRIC COMPANY
P.O. Box 2400
Ft. Smith, AR 72902-2400
(479) 646-4711
Fax (479) 648-5792
www.baldor.com

CH TEL: +41 52 647 4700 FAX: +41 52 659 2394	D TEL: +49 89 90 50 80 FAX: +49 89 90 50 8491	UK TEL: +44 1454 850000 FAX: +44 1454 850001	F TEL: +33 145 10 7902 FAX: +33 145 09 0864
I TEL: +39 11 562 4440 FAX: +39 11 562 5660	AU TEL: +61 29674 5455 FAX: +61 29674 2495	CC TEL: +65 744 2572 FAX: +65 747 1708	MX TEL: +52 477 761 2030 FAX: +52 477 761 2010

Gold Ring™ Solenoid Valve

Installation and Maintenance Instructions



2-Way Remote Pilot Operated
Normally Open and Normally Closed
NEMA 1

Series 24
NPT 3/4, 1, 1-1/4, 1-1/2
Orifice: 3/4, 1, 1-1/8, 1-1/4

Bulletin 7235 Effective 1 Nov 85
Revision C Revised 1 Mar 92

Parker Hannifin Corporation
Fluid Control Division

Catalog Number: 16F24C2164AAF4C05
Voltage: 120

Warnings

1. If you purchase a Unit Valve and a Unit Solenoid, be sure the last two digits of the Unit Valve number match the first two digits of the Unit Solenoid number. If they do not match, do not install.

08F24C2140AAF
AFGC05

Unit Valve
Unit Solenoid
2. Check data label for correct catalog number, pressure, voltage and service. Do not install if unsuitable.
3. For protection and proper operation of the solenoid valve, install a strainer or filter suitable for the service involved as close to the valve inlet as possible.
4. Solenoid valves requires periodic cleaning and inspection depending on the service. This should be done at least once every 12 months or every 500,000 cycles, whichever occurs first.
5. Turn off electrical power supply and line pressure to the valve. Bleed trapped pressure from the lines before inspecting, cleaning, servicing, or repairing the valve.
6. For proper operation be sure that the minimum operating pressure differential is maintained.

Description:

Series 24 offset or remote piloted solenoid valves require a minimum operating pressure for acceptable system operation but permit a greater flow (Cv) than Series 22 solenoid valves. Valves with watertight NEMA Type 4 or explosion-proof NEMA Type 7 enclosures are covered by I & M Instructions, Bulletin 7220.

Operation:

NORMALLY CLOSED

Closed when de-energized; open when energized.

~~**NORMALLY OPENED**~~

~~Open when de-energized; closed when energized.~~

Installation:

1. Application

Refer to Parker Gold Ring™ catalog for application information.

2. Positioning

For best results mount with Unit Solenoid vertical and upright. Unit valve may be mounted in any position.

3. Piping

Connect piping to valve according to markings on valve body. Apply pipe compound or sealing material sparingly to male pipe threads only. If applied to valve thread, it may enter valve and cause operational difficulties. Pipe strain should be avoided by proper support and alignment of piping. Do not use valve as a lever when tightening pipe.

4. Wiring

Wiring must comply with local and national electrical codes. Housings for all solenoids are made with connections for 1/2-inch conduit. The enclosures may be rotated to facilitate wiring.

5. Unit Solenoid Installation

Turn off electrical power supply. Slide unit solenoid over plunger tube. Place data label on top. Squeeze gold ring firmly together, pressing it against the data label. This compresses the anti-vibration fingers.

6. Solenoid Temperature

Standard catalog valves are supplied with coils designed for continuous duty service. When the solenoid is energized for a long period, the solenoid enclosure becomes hot and can be touched with the bare hand for only an instant. This is a safe operating temperature. Excessive heating will be indicated by the smoke and odor of burning coil insulation.

Maintenance:

1. Cleaning

Periodic cleaning of solenoid valves is recommended. Frequency will depend on fluid and service, but should never be less than every 12 months or 500,000 cycles whichever occurs first. In general, if the voltage to the coil is correct, sluggish operation, excessive leakage or noise will indicate cleaning or repair is required. Clean valve filter or strainer when cleaning valve. See valve disassembly and reassembly instructions below.

2. Preventative Maintenance

- a. Keep media flowing through valve as free from dirt and foreign matter as possible.
- b. While not in service, operate valve at least once a month to insure proper opening and closing.
- c. Periodic inspection (depending on media and service conditions) of internal valve parts for damage or excessive wear is recommended. Inspect at least every 12 months or 500,000 cycles, whichever occurs first. Thoroughly clean all parts. Replace worn or damaged parts with Gold Ring™ Spare Parts Kit. Use all parts for best results. Clean valve filter or strainer when cleaning valve.

3. Troubleshooting Guide

a. Faulty Controls Circuit

Check the electrical system by energizing the solenoid. A

metallic click signifies solenoid is operating. Absence of click indicates loss of power supply. Check for loose or blown out fuses, open-circuit or grounded coil, broken lead wires or splices.

b. Burned-Out Coil

Check for open-circuited coil. Replace Unit Solenoid if necessary.

c. Low Voltage

Check voltage across the coil lead. Voltage must be at least 85% of data label rating.

d. Incorrect Pressure

Check valve pressure. Pressure to valve must be within range specified on data label.

e. Excessive Leakage

Disassemble valve and clean all parts. Replace worn or damaged parts with a Gold Ring™ Spare Parts Kit. Use all parts for best results. Install filtration if indicated. See valve disassembly and reassembly instructions.

4. Unit Solenoid Replacement

Turn off electrical power supply and disconnect coil lead wires. Refer to exploded view.

- a. Remove gold ring by inserting a 3/16" wide screwdriver in the curved slot. While holding the gold ring firmly against the unit solenoid gently twist screwdriver counterclockwise. Gold ring will open. Lift off data label and unit solenoid.
- b. Reassembly by sliding unit solenoid over plunger tube. Place data label on top. Press gold ring against data label to compress anti-vibration fingers. Squeeze the gold ring firmly together.

5. Valve Disassembly and Reassembly (Refer to Exploded Views)

Turn off electrical power supply and line pressure. Disconnect coil lead wires. Bleed trapped pressure from lines.

- a. Remove gold ring by inserting a 3/16" wide screwdriver in the curved slot. While holding the gold ring firmly against the unit solenoid gently twist screwdriver counterclockwise. Gold ring will open. Lift off data label and unit solenoid.
- b. Unscrew the plunger tube assembly and remove plunger, spring and body gasket.

- c. Remove body bolts, body, diaphragm spring, diaphragm assembly and body gasket(s).
- d. All parts are now accessible for cleaning or replacement. Replace worn or damaged parts with Gold Ring™ Spare Parts Kit. Use all parts for best results.
- e. Inspect valve body seat for scratches, nicks, dents or other blemishes. Replace if damaged.
- f. Reassemble in reverse order or disassembly, paying careful attention to Exploded Views provided. Apply 175 ± 25 inch pounds of torque to the bonnet and 144 ± 15 inch pounds of torque to the cover screw in a crisscross pattern. The 3/4" NPT requires 110 ± 10 inch pounds of torque when tightening the bonnet. Lubricate all gaskets with Dow Corning Corporations Molykote® III compound or an equivalent high grade silicone grease.

- g. DO NOT alter, modify, or use parts not obtained in Spare Parts Kit from original manufacturer.

Parker Gold Ring™ Spare Parts Kit


Spare Parts Kits and Unit Solenoids are available for Gold Ring™ Valves. Parts marked with an asterisk (*) are included in Spare Parts Kits (See Exploded Views).

Ordering Information For Spare Parts Kits

When ordering Parker Gold Ring™ Spare Kits or Unit Solenoids, specify Valve Catalog Number, Serial Number and Voltage.

Note: This product may contain chemicals known to the state of California to cause cancer, birth defects, or other reproductive harm.

This warning is given in compliance with California Proposition 65, as detectable amounts of chemicals subject to Proposition 65 may be contained in this



Gold Ring TM Solenoid Valve

Installation and Maintenance Instructions



Valves With NEMA 4 Solenoids

Bulletin 7273
Effective 15Oct92
Revision A

Parker Hannifin Corporation
Fluid Control Division

Warnings

1. Check adhesive data label for correct catalog number, pressure, voltage and service. Do not install if unsuitable.
2. Turn off electrical power supply and line pressure to the valve. Bleed trapped pressure from the lines before inspecting, cleaning, servicing or repairing the valve.

Description:

These solenoids are epoxy encapsulated with an integral 1/2" conduit connector that meet the requirements for NEMA Type 4 enclosures. The requirements for the following NEMA enclosure Types are also met: Type 1-General Purpose, Type 2-indoor protection against falling water and dirt, Type 3-outdoor protection against dust, rain, sleet and external ice formation, Type 3R-outdoor protection against rain, sleet and external ice formation, Type 3S-same as Type 3 but in addition provides for operation of external mechanisms when ice laden. Type 4-indoor or outdoor protection against dust, rain, splashing water, hose-directed water and damage from external ice formation, Type 4X-same as Type 4 plus protection against corrosion.

Operation:

For specific valve operation, refer to the valve I & M Instructions.

Installation:

1. Application

Refer to Parker Gold Ring TM catalog for application information.

2. Positioning

The solenoid may be mounted in any position. It is recommended that the solenoid be mounted vertical and upright to prevent accumulation of debris in the plunger tube of the valve.

4. Wiring

Wiring must comply with local and national electrical codes. These coils have a conduit hub for connecting 1/2" conduit. The enclosure may be rotated to facilitate wiring.

5. Solenoid Temperature

Standard catalog valves are supplied with coils designed for continuous duty service. When the solenoid is energized for a long period, the solenoid enclosure becomes hot and can be touched with the bare hand for only an instant. This is a safe operating temperature. Any excessive heating will be indicated by the smoke and odor of burning coil insulation. Ambient and fluid temperature limitations for a solenoid valve depend on the solenoid and the valve materials.

Maintenance:

1. Troubleshooting Guide

a. Faulty Controls Circuit

Check the electrical system by energizing the solenoid. A metallic click signifies the solenoid is operating. Absence of click indicates loss of power supply. Check for loose or blown out fuses, open circuit or grounded coil and broken lead wires.

b. Burned-Out Coil

Check for open-circuited coil. Replace coil if necessary.

c. Low Voltage

Check voltage across the coil lead. Voltage must be at least 85% of adhesive data label rating.


2. Coil Replacement

Turn off electrical power supply and disconnect coil lead wires. Refer to exploded view.

a. Remove retainer ring.


b. Replace old coil with new coil of correct wattage, voltage and class.

c. Reassemble by sliding new unit solenoid over plunger tube assembly. Slide E-ring into the enclosure tube retaining groove. Reconnect your electrical circuit.



OVERALL

ITEM	P/N	DESCRIPTION	QTY	UM
1	10342	TUBING, 3/8" OD X 1/4" ID, POLYETHYLENE	1.00	FT
2	10746	BRACKET, PUMP	2.00	EA
3	1364002	BASE SUB-ASSY. PB600-0	1.00	EA
4	1672006	BOX JUNCTION	1.00	EA
5	1890002	BUMPER, RUBBER	4.00	EA
6	1984005	CABLE ASSY.	1.00	EA
7	*****	CHAMBER ASSY, MIXING (SEE SECTION)	1.00	EA
8	26033	VALVE	1.00	EA
9	2846006	CONTROLLER, REM-1D	1.00	EA
10	2930004	CPLG, PVC, SCH 80 1/2" FPT	1.00	EA
11	*****	FLOWMETER, SUB-ASSY. (SEE SECTION)	1.00	EA
12	5902002	MOTOR	1.00	EA
13	8724903	SWITCH DIFF. PRESSURE	1.00	EA
14	9414003	TUBE BRAIDED SS, 1/2" MPT X 1/2" MPT X 18" LG*	1.00	EA
15	9571341	VALVE SOLENOID	1.00	EA
16	*****	PUMP (SEE SECTION)	1.00	EA
17	1450430	BELT	1.00	EA
18	1693007	BRKT. CHASSIS	2.00	EA
19	1983001	CABLE ASSY., 110V, 8FT GROUNDED, MALE PLG., 16/3	1.00	EA
20	2383003	CHASSIS, BACK	1.00	EA
21	2383004	CHASSIS, FRONT	1.00	EA
22	4684304	GUARD BELT, BOTTOM	1.00	EA
23	4685301	GUARD BELT, TOP	1.00	EA
24	5554000	LABEL, SERIAL PLATE	1.00	EA
25	7070100	PULLEY	1.00	EA
26	7772508	SCREW, MACH, 10-32 X 1/2 SLTD PH, SS	4.00	EA
27	1600312	BOLT, HH, 1/4-20 X 3/4 SS	8.00	EA
28	1600308	BOLT, HH, 1/4-20 X 1/2 SS	10.00	EA
29	1601316	BOLT, HH, 5/16-18 X 1 SS	4.00	EA
30	6020235	NUT, 3/8-24, HEX, SS	2.00	EA
31	7771558	SCREW, MACH, SS PAN HD, PHIL, 8-32 X 1/2	6.00	EA
32	9740300	WASHER, SS, FLAT 1/4"	20.00	EA
33	9741300	WASHER, SS, FLAT, 5/16	4.00	EA
34	9741315	WASHER, SS, SPLIT, LOCK 5/16"	4.00	EA
35	9742300	WASHER, SS, FLAT, 3/8	2.00	EA
36	6020962	NUT, 8-32, HEX	2.00	EA
37	2577264	ELBOW, CONDUIT	3.00	EA
38	2726564	CONNECTOR CORD GRIP	1.00	EA
39	2726562	CONNECTOR W/JACKET 1/2 MPT	1.00	EA
40	5551210	LABEL, POLYBLEND	1.00	EA



600
D-010


MIXING CHAMBER 2341101

ITEM	PART NO.	DESCRIPTION	QTY.
1	1411001	BEARING	1
2	1414001	BEARING, THRUST	1
3	1600308	BOLT, HH, 1/4-20 X 1/2	2
4	1600341	BOLT, HH, 1/4-20 X 5	2
5	2124006	CAP, TOP, MIXING CHAMBER	1
6	2124007	CAP, BOTTOM, MIXING CHAMBER	1
7	2650002	COLLAR	2
8	5173601	IMPELLER, PRIMARY	1
9	5173602	IMPELLER, SECONDARY	1
10	5993002	NOZZLE, MIX CHAMBER (MANNICH POLYMER)	1
11	6020031	NUT, 1/4-20, HEX, SS	8
12	6023031	NUT, ACORN, 1/4", S.S.	4
13	6091802	O-RING	2
14	6676001	PLATE, BAFFLE	1
15	7070412	PULLEY	1
16	7802910	SEAL, MECHANICAL	1
17	7854304	SHAFT	1
18	8603001	STUD	4
19	9412801	TUBE, ACRYLIC	1
20	9572323	VALVE, INJ. CHECK	1
21	9740300	WASHER, FLAT, 1/4"	10
22	9740330	WASHER, SS, INT TOOTH, 1/4"	2
23	RM6600021	1/4" S-80 PVC PIPE	1

SOURCE OF SUPPLY FOR PARTS


Siemens Water Technologies
595 Industrial Drive
Bradley, IL 60915
PHONE: 800-882-6466
FAX: 815-932-0674

MIXING CHAMBER 2341101



FLOWMETER ASSEMBLY – P/N 4303105

ITEM	PART NO.	DESCRIPTION	QTY.	UM
1	1048005	ADAPTER, SPUD	1	EA
2	3581634	ELBOW, BRASS, 1/4" MPT X 3/8" OD COMP	1	EA
3	4293101	FLOWMETER, KING, 10GPM	1	EA
4	6091302	O-RING, BUNA N	4	EA
A	1040094	ADAPTER, OUTLET, FLOWMETER	1	EA
B	1048402	ADAPTER	1	EA
C	6720702	TOP PLUG, KING	1	EA
D	9579302	VALVE, KING	1	EA



Items with alphabetical callouts are components of Item #3. They are shown here in case you wish to order replacement parts.

SOURCE OF SUPPLY FOR PARTS


Siemens Water Technologies
 595 Industrial Drive
 Bradley, IL 60915
 PHONE: 800-882-6466
 FAX: 815-932-0674

Blank Page

Instruction **Supplement**

Series AA7

Electronic Metering Pump




Metering Pump Component Diagram



201 Ivyland Road
Ivyland, PA 18974 USA
TEL: (215) 293-0401
FAX: (800) 327-7563
<http://www.lmipumps.com>

Series AA7 Drive Assembly Exploded View Diagram




Series AA7 Drive Assembly Parts List


Key No.	Model Series	Part No.	Description	Qty.
1	AA741, AA751, AA761, AA771, AA781	48016	Control Panel Assembly, 115V	1
	AA742, AA752, AA762, AA772, AA782	48017	Control Panel Assembly, 230-250V	1
	AA743, AA753, AA763, AA773, AA783			
	AA745, AA755, AA765, AA775, AA785			
	AA746, AA756, AA766, AA776, AA786			
	AA747, AA757, AA767, AA777, AA787			
2	AA741, AA751	48034	EPU w/ Stroke Adjustment, 115V	1
	AA742, AA743, AA745, AA746, AA747	48035	EPU w/ Stroke Adjustment, 230-250V	1
	AA752, AA753, AA755, AA756, AA757			
	AA761	48036	EPU w/ Stroke Adjustment, 115V	1
	AA762, AA763, AA765, AA766, AA767	48037	EPU w/ Stroke Adjustment, 230-250V	1
	AA771, AA781	48038	EPU w/ Stroke Adjustment, 115V	1
3	AA772, AA773, AA775, AA776, AA777	48039	EPU w/ Stroke Adjustment, 230-250V	1
	AA782, AA783, AA785, AA786, AA787			
	AA741, AA751	48025	EPU, 115V	1
	AA742, AA743, AA745, AA746, AA747	48026	EPU, 230-250V	1
	AA752, AA753, AA755, AA756, AA757			
	AA761	48027	EPU, 115V	1
90	AA762, AA763, AA765, AA766, AA767	48028	EPU, 230-250V	1
	AA771, AA781	48029	EPU, 115V	1
	AA772, AA773, AA775, AA776, AA777	48030	EPU, 230-250V	1
	AA782, AA783, AA785, AA786, AA787			
100	AA7	10973	Seal	1
105	AA7	38886	Stroke Adjustment Bracket	1
120	AA7	48012	Stroke Adjustment Shaft Assembly	1
130	AA7	41227	Screw	8
	AA741, AA751, AA761, AA771, AA781	29033CE	Power Cord Assembly, 115V	1
	AA742, AA752, AA762, AA772, AA782	29039CE	Power Cord Assembly, 230V US	1
	AA743, AA753, AA763, AA773, AA783	29042CE	Power Cord Assembly, 230V DIN	1
	AA745, AA755, AA765, AA775, AA785	29044CE	Power Cord Assembly, 240V UK	1

Key No.	Model Series	Part No.	Description	Qty.
140	AA7	37879	Foot	1
150	AA7	38199	Screw	3
190	AA7	34497	O-Ring	1
200	AA741, AA751, AA761, AA771, AA781	37734	Pulser, 120V	1
	AA742, AA752, AA762, AA772, AA782	37735	Pulser, 230-250V	1
	AA743, AA753, AA763, AA773, AA783			
	AA745, AA755, AA765, AA775, AA785			
	AA746, AA756, AA766, AA776, AA786			
	AA747, AA757, AA767, AA777, AA787			
210	AA7	10422	Retaining Ring	1
220	AA741, AA751, AA761, AA771, AA781	35243	MOV and Capacitor Assy, 115V	1
	AA742, AA752, AA762, AA772, AA782	35237	MOV and Capacitor Assy, 230-250V	1
	AA743, AA753, AA763, AA773, AA783			
	AA745, AA755, AA765, AA775, AA785			
	AA746, AA756, AA766, AA776, AA786			
	AA747, AA757, AA767, AA777, AA787			
230	AA7	35743	Speed Shaft	1
240	AA7	35744	Dual Pin	1
250	AA7	30803	Gasket	1
260	AA7	30709	Speed Knob	1
280	AA7	38887	Gasket	1
300	AA7	41244	Screw	1
340	AA76	30374	Stroke Dial	1
	AA77	29269	Stroke Dial	1
	AA78	29268	Stroke Dial	1
350	AA7	31890	Stroke Knob Assembly	1
380	AA74, AA77	29445	Disk, 0.5	1
	AA75, AA78	29437	Disk, 0.9	1
	AA76	29442	Disk, 1.8	1
390	AA7	37974	Cover	1

Series AA7 Control Panel Detail




Series AA7 Wiring Diagram




BAR = 1" AT PLOT SCALE

INTL REF:


STD: BORDER-0106-11X17B




TOP VIEW




REAR VIEW




LEFT SIDE VIEW



FRONT VIEW



RIGHT SIDE VIEW



ISOMETRIC VIEW

PB UNIT	PUMP OUTPUT	ROTAMETER RANGE
PB600-1	0-1GPH	60-600GPH
PB600-1K	0-3.8GPH	240-2400GPH
PB600-2	0-2GPH	60-600GPH
PB600-2A	0-7.6LPH	240-2400LPH
PB600-2K	0-7.6LPH	240-2400LPH
PB600-2.5	0-2.5GPH	60-600GPH
PB600-2.5K	0-9.5LPH	240-2400LPH
PB600-4.5	0-4.5GPH	60-600GPH
PB600-4.5A	0-17LPH	60-600GPH
PB600-4.5K	0-17LPH	60-600GPH
PB600-8	0-8GPH	60-600GPH
PB600-8A	0-30LPH	60-600GPH
PB600-10	0-10GPH	60-600GPH

KEY	DESCRIPTION
1	DISCHARGE, 1" (F)NPT
2	POWER CORD (NOT SHOWN)
3	POLYMER INLET, 1/2" (F)NPT
4	WATER INLET, 1" (F)NPT
5	PRIMING PORT, (PUMP)
6	SOLENOID VALVE, (WATER)
7	DIFFERENTIAL PRESSURE SWITCH
8	DELTA P ADJUSTMENT SCREW
9	MIX CHAMBER
10	DIGITAL DISPLAY PUMP CONTROLLER, (REM-1E)
11	ROTAMETER
12	DIAPHRAGM PUMP
13	RATE VALVE
14	4-20mA INPUT
15	MIXER MOTOR
16	MANUAL RESET THERMAL PROTECTOR
17	JUNCTION BOX
18	MAIN/POWER SWITCH
19	MIXER MOTOR SWITCH
20	AUXILIARY PORT

COMPANY CONFIDENTIAL THIS DOCUMENT AND ALL INFORMATION CONTAINED HEREIN ARE THE PROPERTY OF SIEMENS AND/OR ITS AFFILIATES. THE DESIGN CONCEPTS AND INFORMATION CONTAINED HEREIN ARE PROPRIETARY TO SIEMENS AND ARE SUBMITTED IN CONFIDENCE. THEY ARE NOT TRANSFERABLE AND MUST BE USED ONLY FOR THE PURPOSE FOR WHICH THE DOCUMENT IS EXPRESSLY LOANED. THEY MUST NOT BE DISCLOSED, REPRODUCED, LOANED OR USED IN ANY OTHER MANNER WITHOUT THE EXPRESS WRITTEN CONSENT OF SIEMENS. IN NO EVENT SHALL THEY BE USED IN ANY MANNER DETRIMENTAL TO THE INTEREST OF SIEMENS. ALL PATENT RIGHTS ARE RESERVED. UPON THE DEMAND OF SIEMENS, THIS DOCUMENT, ALONG WITH ALL COPIES, AND EXTRACTS, AND ALL RELATED NOTES AND ANALYSES, MUST BE RETURNED TO SIEMENS OR FILED FOR DESTRUCTION, AS INSTRUCTED BY SIEMENS. ACCEPTANCE OF THE DELIVERY OF THIS DOCUMENT CONSTITUTES AGREEMENT TO THESE TERMS AND CONDITIONS.							DESIGNER BROWN	DATE 02-07-94	TITLE GENERAL ARRANGEMENT DRAWING PB600 SERIES (STANDARD UNIT)				
							CHECKER GIDDINGS	DATE 07-14-99	CLIENT				
							ENGINEER COULTER	DATE 07-14-99	SIEMENS Water Technologies BRADLEY, IL 815-932-8154 FAX 815-932-0674				
							MANAGER D'DOWD	DATE 07-14-99					
REV	DESCRIPTION	DATE	DWN	CHKD	APVD	ECN	SCALE: 1:1	PB600-DX	PROJECT	CODE PB600	DRAWING PB600-DX-AD	SHEET 1 OF 1	REV 5

