

OPERATING & INSTRUCTION MANUAL

NEPTUNE SERIES 7000 Mechanically Actuated Diaphragm PUMP MODELS MP7100, MP7120, MP7130, MP7150, MP7180



**295 DeKalb Pike,
North Wales, PA 19454**

Tel.: 215-699-8700 • FAX: 215-699-0370
www.neptune1.com

WARNING

**LOCKOUTS ARE REQUIRED BEFORE
SERVICING THIS EQUIPMENT.**

SAFETY INSTRUCTIONS:

Shut off/Lockout Pump Power before Servicing.

**Be certain pump isolation valves are
Closed and chemical is shut off.**

Bleed pressure before servicing.

WARNING

Please read thoroughly before installation, operation or maintenance of any Neptune pump

EQUIPMENT MISUSE HAZARD

Equipment misuse can cause the equipment to rupture, malfunction and result in serious injury.

- This equipment is for professional use only.
- Read all instruction manuals, tags and labels before operating the equipment.
- Use the equipment only for its intended use.
- Do not alter or modify this equipment.
- Be certain all operators of this equipment have been trained for safe working practices, understand its limitations and wear safety goggles and or equipment when required
- Do not exceed the maximum working pressure of the system as mentioned on the pump tag.
- Do not use the pump head or the suction or discharge piping to pull the equipment.
- Do not move pressurized pump.
- Use fluids or cleaning agents for cleaning that are compatible with the pump parts. Read the fluid and cleaning agent manufacturer's warning and also refer to the material compatibility chart.
- Comply with all applicable local, state and national safety regulations.
- Do not allow the pump to run dry for long periods.

PRESSURIZED EQUIPMENT HAZARD

Spray from leaks, ruptured components can splash fluid in eyes or on skin and cause serious injury.

Leaks from ruptured components • • • • •

- Shut off the pump and depressurize before performing any maintenance.
- Do not tamper with or perform unspecified alteration of the device.
- Use only pipes, hoses and hose fittings rated for maximum rated pressure of the pump or the pressure at which the pressure relief valve is set at.
- Always wear protective clothing, face shield, safety glasses and gloves when working on or near the metering pump.
- Additional precautions should be taken depending on the solution being pumped. Refer to SDS precautions from your solution supplier.
- Do not stop or deflect fluid leaks with your hands, body, gloves or rags.
- Tighten all fluid connections before operating the equipment.
- Replace worn damaged or loose parts immediately.
- Before performing any maintenance requiring pump head and or valve (wetting parts) disassembly, be sure to relieve pressure from the piping system and where hazardous process chemicals are present.
- Make the pump safe to handle for individuals and the environment by leaning and chemically neutralizing the pump when appropriate.
- Wear protective clothing and use proper tools as appropriate to avoid any injury.
- If the diaphragm has failed, process chemical may have contaminated the pump oil. Handle with appropriate care and personnel equipment. Clean the pump and replace oil as necessary. Discard the contaminated oil as per the local code.

FIRE AND EXPLOSION HAZARD

Improper grounding, poor air ventilation, open flames, or sparks can cause a hazardous condition and result in fire or explosion and serious injury.

- Ground the equipment. See motor installation instruction for grounding procedure.
- Do not pump non recommended flammable or explosive fluids.
- Static electricity may generate by fluid moving through pipes and hoses. A static spark could be produced by high fluid flow rates. Grounding of the pump is a must.
- Provide fresh air ventilation to avoid the possible buildup of flammable fumes from the process chemicals.
- Keep the pump area free of debris, including cleaning agent, rags, and any flammable material.
- Follow the cleaning agent and other cleaning recommendations as mentioned in the operation and instruction manuals.
- Use cleaning agent with the highest possible flash point to clean the pump parts if needed.
- If there is any static sparking while using the equipment, stop operation at once. Identify and correct the problem before starting up the pump.

TOXIC FLUID HAZARD

Hazardous fluids or toxic fumes can cause serious injury or death if splashed in eyes or on the skin, swallowed, or inhaled.

- Know the specific hazards of the fluid you are using. Read the fluid manufactures warnings.
- Store hazardous fluid in an approved container. Dispose of hazardous fluid according to all local, state and national guidelines.
- Wear the appropriate protective clothing, gloves, eyewear and respirator.
- Pipe and dispose of the exhaust air safely. If diaphragm fails, the fluid may be exhausted along with the air in mechanical diaphragm pump. Also oil vapor may flow through the air breather installed on the gear box.

SOUND HAZARD

The sound pressure level of the pump may exceed 80dBA in some pumps.

- Observe all safety precautions when operating the pump within close proximity for extended periods by wearing hearing protectors.
- Extended exposure to elevated sound levels will result in permanent loss of hearing acuteness, tinnitus, tiredness, stress, and other effects such as loss of balance and awareness.

MECHANICAL HAZARD

The pump may shake or vibrate during operation.

- Vibration could occur due to loose mechanical component and foundation bolts, causing piping rupture and leakage of chemical to cause bodily injury. The pump should be bolted down to the base during operation.
- Spills or drips of oil may occur during maintenance of pump, causing the operator to slip or fall. Clean and neutralize the area as soon as possible with an appropriate cleaning agent. Always wear protective clothing and gears.
- Pump may overturn when being transported if the motor is too heavy. Secure the pump on its base before transportation.

SECTION	PARAGRAPH	TABLE OF CONTENTS	PAGE
I		GENERAL DESCRIPTION	5
		LIMITED WARRANTY	6
		PARTS ORDERING INSTRUCTIONS	7
II		INSTALLATION INSTRUCTIONS	
	1	GENERAL	8
	2	SUCTION PIPING	9
	3	DISCHARGE PIPING	10
	4	INSTALLATION OUTDOORS	10
	5	STARTUP PROCEDURE	10
III		NORMAL MAINTENANCE	
	6	MAINTENANCE	11
		PARTS LIST	17
		COMMON PARTS LIST	17
		GEAR BOX PARTS LIST PER MODEL	17
		LIQUID HEAD PARTS LIST PER MODEL	18,19
IV	7	MOTOR OPERATING CONDITIONS	20
V		TROUBLE SHOOTING CHART	20
		DRAWINGS	
		MODEL MP7120-3N5 MECHANICALLY ACTUATED PUMP	13-16
		CROSS SECTION (HEAD AREA) MP7120-2N5,-2N8	18
		SPARE PARTS KITS	21
		PUMP DATA / MAINTENANCE LOG	22

SECTION I

GENERAL DESCRIPTION

The Neptune MP7000 Mechanical Diaphragm metering pump is a reliable metering pump of the low-pressure diaphragm type. Under constant conditions of temperature, pressure, and capacity setting, a +/- 2% metered discharge volume is maintained. Rugged contoured composite diaphragm designed for high metering accuracy over a full 10:1 turndown range.

A reciprocating rod at a set stroke length and rate actuates a flexible, chemically inert, Teflon faced diaphragm creating the pumping action. Screwing in and out a hand knob regulates the capacity of the pump. Screwing in shortens the stroke length reducing the volume and screwing out increases capacity. A percentage of flow is read on the hand knob.

Precision-engineered liquid ends meters mild solutions, aggressive chemicals, high viscosity polymers (up to 2500cP) and slurries (hydrated lime slurries up to 4 lb/gallon of water, activated carbon slurries up to 1 lb/gallon of water). If metering of liquids with higher viscosity is required please contact factory

Metering accuracy is maintained by the ball check valves in the suction and discharge pump heads. Screw-in cartridge ball check valves eases maintenance.

Temperature limitations on the plastic heads are: 36 – 125°F (2 - 52°C) for PVC; 36 - 200°F (2-93°C) for PVDF.

PLEASE READ INSTRUCTION MANUAL COMPLETELY BEFORE INSTALLING PUMP.

SECTION I

NEPTUNE CHEMICAL PUMP COMPANY LIMITED WARRANTY

All Neptune Pumps are tested at the factory prior to shipment. Each part used in their construction has been carefully checked for workmanship.

If the pump is installed properly, Neptune Chemical Pump Company warrants to the purchaser of this product for a period of twelve months from the date of first use or eighteen months from shipment, whichever occurs first, this product shall be free of defects in material and/or workmanship, as follows:

- 1 Neptune Chemical Pump Company will replace, at no charge, any part that fails due to a defect in material and/or workmanship during the warranty period, FOB our factory, North Wales, Pennsylvania. To obtain warranty service, you must forward the defective parts to the factory for examination, freight pre-paid.¹
- 2 This warranty period does not cover any product or product part, which has been subject to accident, misuse, abuse or negligence. Neptune Chemical Pump Company shall only be liable under this warranty if the product is used in the manner intended by the manufacturer as specified in the written instructions furnished with this product.

Any express warranty not provided in this warranty document, and any remedy for breach of contract that, but for this provision, might arise by implication or operation of law, is hereby excluded and disclaimed. Under no circumstances shall Neptune Chemical Pump Company be liable to purchaser or any other person for any charge for labor, repairs, or parts, performed or furnished by others, nor for any incidental consequential damages, whether arising out of breach of warranty, express or implied, a breach of contract or otherwise. Except to the extent prohibited by applicable law, any implied warranty of merchantability and fitness for a particular purpose are expressly limited in duration to the duration of this limited warranty.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long any implied warranty lasts, so the above limitations may not apply to you. This warranty gives you specific legal rights, and you may have other rights, which may vary from state to state.

IMPORTANT

SHOULD IT BE NECESSARY TO SEND THE PUMP TO THE FACTORY FOR REPAIR OR MAINTENANCE REBUILDING; DRAIN ALL OIL AND CHEMICAL FROM PUMP BEFORE SHIPPING. FAILURE TO DO SO CAN CAUSE EXTENSIVE DAMAGE TO THE MOTOR.

¹SEE IMPORTANT NOTICE –RETURN GOODS AUTHORIZATION

IMPORTANT NOTICE RETURN GOODS AUTHORIZATION

- (1) All equipment returned to Neptune Chemical Pump Company requires proper Returned Goods Authorization Number (RGA) and tags.
- (2) All equipment returned to the factory for repair or service must first be thoroughly flushed and have all chemical contact areas neutralized.
- (3) All equipment which has been in contact with chemicals must be accompanied by a copy of the chemical product material Safety Data Sheet (SDS).
- (4) Failure to comply with the above instructions will result in equipment being returned to sender, freight collect, without service.

SECTION I

PARTS ORDERING INSTRUCTIONS

The complete model number and serial number of the pump must be furnished to insure prompt and accurate parts service. These numbers are found on the name plate (sample below) located on the back cover of the pump.

Please refer to page number (17), (18), (19) for parts list. Ballooned drawing of the pumps can be found on pages (13), (14), (15), (16) and (18).

Spare Parts Kits are found on page 21.



Send all orders or inquiries for parts to:

Parts Department
Neptune Chemical Pump Company, Inc.
295 DeKalb Pike
North Wales, PA 19454
Tel.: 215-699-8700
1 -888-3NEPTUNE (888-363-7886)
FAX: 215-699-0370
Web: www.neptune1.com
Email: neptune.sales@psgdoover.com

NOTE: PLEASE SUPPLY BOTH MODEL AND SERIAL NUMBERS.

SECTION II

INSTALLATION INSTRUCTIONS

1.0 GENERAL

1.0.1 UNPACKING & INSPECTION

When unpacking a pump or chemical feed system, be certain that no parts are thrown away. Examine the equipment for possible damage. If damage has occurred, file a claim with the common carrier within 24 hours. Neptune will assist in estimating the repair costs.

1.0.2 The Mechanically Actuated Diaphragm metering pumps should be located on a level surface. Four mounting holes are provided to anchor the pump base securely to the mounting surface. All piping to the pump should be supported to prevent stress on the pump inlet and discharge fittings.

1.0.3 Before connecting the pump make sure that all fittings are completely clean by flushing thoroughly. Foreign matter with sharp edges entering the pump can damage the diaphragm and severely limit the life of the pump.

1.0.4 A "Y" STRAINER (AT LEAST ONE PIPE SIZE LARGER THAN SUCTION PORT SIZE OF THE PUMP) MUST BE INSTALLED IN THE SUCTION LINE OF THE PUMP TO INSURE AGAINST FOREIGN MATTER ENTERING THE PUMP

1.0.5 It is recommended that isolation valves and unions be placed in the suction and discharge lines if possible. Such an arrangement will facilitate servicing the pump.

1.0.6 The electrical supply to the pump must match the motor nameplate characteristics. The motor rotation is counterclockwise when viewed from the top of the motor or looking down on the pump. An arrow mark on the side cover of the gearbox is indicating the correct rotation (Figure 1).




FIGURE 1

Operation with the incorrect rotation will damage the pump and motor.

IMPORTANT: On single-phase units, the rotation is set at the factory and must not be changed

- 1.0.7 Fill gearbox and pump by removing the breather and pouring the specified gear oil (drive lubricant) or oil provided with pump through the Breather port. Pour oil in slowly until it covers the worm gear.
- 1.0.8 For dry pump (pump shipped from factory without oil) the oil volume is 27ozs (800cc) to fill the pump.

The oil supplied by Neptune is: PREMIUM PERFORMANCE HYPOID GEAR OIL SAE 80W-90, Neptune P/N 104690

Common sources for Gear Oil are:

Alternate Oils	Manufacturer
Spirax S3 80W-90 Advance transmission Hypoid Gear Oil	Shell Oil
Mobil Delvac Gear Oil 80W-90	Mobil Oil
MULTIGEAR 80W-90 Geartex EP-A 85W-90	Texaco
Pennzoil® Gearplus® SAE 80W- 90 GL-5 Gear Oil	Pennzoil

NOTE: THE FACTORY SUPPLIED CHECK VALVES ARE FITTED WITH VITON O-RINGS. CHECK CHEMICAL COMPATIBILITY, IF NOT COMPATIBLE REPLACE WITH SUPPLIED TEFLON O-RINGS.

All piping systems should include:

- 1.1.1 A separate system relief valve to protect piping and process equipment, including the pump, from excess process pressures.
- *An **external relief valve** is required to safeguard pump and the piping system.
- 1.1.2 Isolation valves and unions (or flanges) on suction and discharge piping. This permits check valve inspection without draining long runs of piping. Isolation valves should be of the same size as connecting pipe. Full flow ball valves are preferred since they offer minimum flow restriction.
 - 1.1.3 An inlet strainer, if the product is not slurry. Pump check valves are susceptible to dirt and other solid contaminants unless designed for that service, and any accumulation can cause malfunction. The strainer should be located between the suction isolation valve and the pump suction check valve. It must be sized to accommodate the flow rate and the anticipated level of contamination. A 100-mesh screen size is recommended.
 - 1.1.4 Check valve housings or other portions of the liquid head must not support piping weight, as the resulting stresses can cause leaks. In piping assembly, use a sealing compound chemically compatible with the process material.

SUCTION PRESSURE REQUIREMENTS

Although Mechanical Diaphragm metering pumps have suction lift capability, a flooded suction is preferable whenever possible. The pump should be located as close as possible to the suction side reservoir or other source keeping suction piping as short as possible.

The pump will self-prime with 10 ft. (3 meters) of water suction lift (wetted valves, zero back pressure, full stroke and speed, water like solutions). A foot valve is required to maintain prime. Once primed, the pump is capable of up to 20 feet (6 meters) of water suction lift.

Neptune Mechanically Actuated Diaphragm metering pumps are designed for continuous service at the rated discharge pressure. The discharge pressure must exceed suction pressure by at least 25 psiA (or 1.75 Bar). This can be achieved where necessary by the installation of a backpressure valve in the discharge line.

2.0 SUCTION PIPING

- 2.0.1 The suction piping to the pump must be absolutely airtight for optimum operation. Any leakage in the suction line will reduce or even eliminate pumping capacity. Suction pipe should be at least one size larger than suction port size of the pump's Liquid Head. It is suggested that the suction piping be tested with low air pressure and a soap solution to assure that no leaks exist. Limit the total length of the suction line to 5-8 feet for suction lift or 8-10 feet for flooded suction. Minimize bends, elbows, or other restrictions for better pumping efficiency.
- 2.0.2 NEPTUNE RECOMMENDS THAT THE MECHANICALLY ACTUATED DIAPHRAGM METERING PUMPS BE OPERATED WITH A FLOODED SUCTION, AS THIS WILL FACILITATE START-UP AND INCREASE THE SERVICE LIFE OF THE PUMP.
- 2.0.3 It is recommended that all solution tanks be furnished with a low level cut off switch or low-level alarm and cut off switch to prevent the pump from running dry. Although the pump can run dry for a few minutes, OPERATION AGAINST A DRY SYSTEM UNDER PRESSURE FOR A PROLONGED PERIOD MAY CAUSE DAMAGE TO THE PUMP DIAPHRAGM AND REDUCE THE OPERATING LIFE OF THE PUMP.

3.0 DISCHARGE PIPING

- 3.0.1 It is recommended that the Mechanically Actuated Diaphragm metering pump operate against a suitable back pressure to facilitate better operation of the check valves.
- 3.0.3 To protect the pump, it is recommended that an external relief valve as manufactured by Neptune Chemical Pump Company, or equal, be placed in the discharge line of the pump to avoid over pressure.
- 3.0.4 Discharge piping should at least equal to discharge port size of the pump's Liquid Head.

NOTE: All pipes and valves must have a working pressure at least twice the system maximum pressure.

CAUTION : Do not attempt to run the pump in excess of its nameplate rating.

4.0 INSTALLATION OUTDOORS

The Mechanically Actuated Diaphragm metering pump is a totally enclosed pump, which can be used outdoors or indoors. When installed outdoors, make sure that the pump is protected against extremes of nature as follows:

- 4.0.1 Running of the pump when exposed to tropical sunshine with ambient temperature above 100°F (37.8°C) would cause excessive oil and motor temperatures. The pump should be shaded and located in such a way as to permit an ample degree of air circulation.
- 4.0.2 Under cold conditions, the pump should be insulated and a heat tracing should be supplied in order to maintain the hydraulic fluid at an ambient temperature above 36°F (2°C.)

5.0 START UP PROCEDURE

The following start up procedure is complete and does repeat instructions on filling the gearbox and pump.

- 5.0.1 Open suction and discharge valves. (See recommendation 1.0.5)
- 5.0.2 Set capacity control knob to indicate zero by turning clockwise.
- 5.0.3 Adjust backpressure close to zero.
- 5.0.3 Start pump.
- 5.0.4 On initial start-ups: Check for proper motor rotation (Refer to Paragraph 1.0.6). Listen for any abnormal motor or crank noises, and if present, refer to trouble shooting chart (page 20)
- 5.0.5 Adjust pump to required capacity by turning hand knob counterclockwise.

5.0.6 Adjust system pressure to requirement.

SECTION III

NORMAL MAINTENANCE

6.0 MAINTENANCE

Under normal conditions, the Mechanically Actuated Diaphragm metering pumps should not require any significant amount of maintenance. It is advised that periodic visual observations be made of the oil level to make sure that it is over the worm gear. The liquid end of the pump should also be inspected for leakage and check the liquid head bolt torque. These observations should be made regularly.

The gear oil should be drained and replaced at least every 6 months. Oil changes are usually scheduled with the normal factory maintenance at seasonal periods. The recommended oil change intervals are dependent upon the operating environment and hours of pump usage.

6.1.0 OIL CHANGE

- 6.1.1 Disconnect the power source to the drive motor
- 6.1.2 Relieve all pressure from the piping system.
- 6.1.3 Drain the oil by removing the drain plug (item#71) at the lower side of the gearbox.
(Same side where the side cover is located)
- 6.1.4 Replace the drain plug (item#71)
- 6.1.5 Remove breather from the gearbox.
- 6.1.6 Fill gear box with oil as recommended in 1.0.7
- 6.1.7 Replace breather.

6.2.0 CHECK VALVE REMOVAL CLEANING AND REPLACEMENT.

Should the valves need cleaning, remove as follows:

- 6.2.1 Disconnect the power source to the drive motor.
- 6.2.2 Relieve all pressure from the piping system.
- 6.2.3 Close the isolation valves on suction and discharge piping.
- 6.2.4 Loosen and remove the suction and discharge check valves gradually to drain any trapped liquid.
- 6.2.5 Clean valves with suitable solvent. Both valves are complete and integral units and should not be disassembled for cleaning. If the valves are found to be worn and in need of replacement, an entire valve in either suction or discharge should be ordered.
- 6.2.6 To replace, reverse above procedures. Make sure that the port orientation is correct.
- 6.2.7 For valves with O-rings make sure that the O-rings are in good condition. Install new O-rings if necessary.

LIQUID HEAD REMOVAL, INSPECTION, AND REINSTALLATION


CAUTION: If the diaphragm failed, process fluid will pass through the bleed hole located behind the diaphragm. Handle any liquid with appropriate care. (Refer to liquid manufacturer's SDS)

Mechanical diaphragms should operate for approximately 2000+ hours under normal operating conditions; however, the accumulation of foreign material or debris and abnormal operating condition or simply age can cause failure. Failure can also occur as a result of hot pumping fluid or system over pressure. Periodic diaphragm inspection and replacement are recommended.


- 6.3.1 Adjust the stroke control knob to "0" and disconnect the power source to the drive motor.
- 6.3.2 Relieve all system pressure from the piping system.
- 6.3.3 Take all precautions described under "Caution" to prevent environmental and personnel exposure to hazardous materials.
- 6.3.4 Disconnect piping to the Liquid Head and drain any process liquid.
- 6.3.5 Drain gear box oil.
- 6.3.6 Place a pan underneath the pump head adaptor to catch any liquid leakage.
- 6.3.7 Remove all but two top Liquid Head bolt. Process fluid or Oil or both will leak out between the pump head adaptor and Liquid Head as the bolts are loosened.
- 6.3.8 Tilt the head and pour out any liquids retained by the check valves into a suitable container, continue to follow safety precautions as appropriate.
- 6.3.9 Remove the final bolt and rinse or clean the Liquid Head with an appropriate material.
- 6.3.10 Inspect the diaphragm. The diaphragm must be replaced if it is cracked, separated, or obviously damaged. Remove the diaphragm if necessary, by turning counter-clockwise.
- 6.3.11 If diaphragm cannot be unscrewed from push rod, remove 1/8 NPT dry seal plug (item #69) from the interim chamber.
- 6.3.12 Use a 1/8" diameter steel implement, insert it through the hole for the dry seal plug and into the cross hole in the push rod. Start to turn diaphragm to feel the steel implement engage the hole in push rod. This will lock the push rod from turning with diaphragm allowing diaphragm removal.
- 6.3.13 To install a diaphragm, first ensure that the critical sealing areas of: diaphragm, Liquid Head, and pump head adapter are clean and free of debris. Assemble the diaphragm with backup plate (item #28). For MP71XX-3N3, 5, 8 and MP71XX-4N3, 5, 8 install spacer nut (item #30) onto the diaphragm threads.
- 6.3.14 Thread the diaphragm (clockwise) completely on the push rod. Use step 6.3.11 to hold push rod in place when turning the diaphragm. Put back dry seal plug in interim chamber, and add oil as specified in 6.1.0.
- 6.3.15 Install the liquid head, faceplate (for plastic heads), and bolts. Tighten bolts in an alternating crossing pattern to ensure an even pressure on all bolts. Recommended torque is 12-13 ft-lb for pump MP 71XX-2N3, 5, 8 and 18-19 ft-lb for pump MP71XX-3N3, 5, 8, MP71XX-4N3, 5, 8.

**MODEL MP7120-3N5 MECHANICALLY ACTUATED PUMP
(SHOWN WITH PVC #3 LIQUID HEAD)**


HORIZONTAL CROSS SECTION




VERTICAL CROSS SECTION A-A



PUMP SIDE VIEW (LEFT SIDE)



PUMP SIDE VIEW (RIGHT SIDE)



PARTS LIST

COMMON PARTS LIST

ITEM NO.	DESCRIPTION	QTY.	PART NO.
1	Gear Box	1	004760
2	GEARS		
	Worm Gear 37 SPM*		004778
	Worm Gear 72 SPM*		004779
	Worm Gear 58 SPM*		004780
	Worm Gear 117 SPM*		004781
	Worm Gear 176 SPM*		004782
3	SIDE COVER	1	005124
4	O-RING, VITON	1	104756
6	SLEEVE BUSHING FOR ALUM GEAR BOX	2	104673
7	GEAR SHAFT	1	104677
8	THRUST COLLAR	1	004785
9	PUSH ROD	1	004786
10	BUSHING	1	104674
11	O-RING, VITON	2	104757
12	INTERMEDIATE CHAMBER	1	004849
13	METERING SHAFT CONTROL KNOB ADAPTER	1	004418
14	HAND KNOB, MECH DIAPH PUMP	1	100314
15	SET SCREW, 1/4-20	1	105017
16	SPRING PIN	1	100305
17	STROKE CONTROL CHAMBER COVER	1	004766
18	CAPACITY INDICATING SCALE	1	100306
19	O-RING, VITON	1	100417
20	O-RING, NITRILE	1	107580
21	O-RING, VITON	1	108092
24	RETAINING RING EXTERNAL	2	106593
31	RETAINING RING INTERNAL	2	106592
32	OIL SEAL	2	106586
33	O-RING, NITRILE	1	107600
34	BUSHING	1	104675
35	SPRING	1	108023
38	BACK COVER MECH DIAPH PUMP	1	004793

ITEM NO.	DESCRIPTION	QTY.	PART NO.
40	WORM	1	
	WORM 37 SPM		000170
	WORM 72 SPM		000172
	WORM 58 SPM		004710
	WORM 117 SPM		000169
	WORM 176 SPM		000171
41	BEARING WAVE SPRING	1	107599
42	BALL BEARING	1	106180
43	MOTOR FLANGE ADAPTER, 56C & IEC 71	1	004812
44	MOTOR WORM SHAFT	1	004156
45	BREATHER	1	000191
48	BOLT	2	100267
49	BEARING CUP	1	100179
50	BEARING CONE	1	100180
51	SPRING PIN	1	100181
52	SCREW	4	105108
58	LOCK WASHER	20	100170
59	NUT	16	108175
60	BOLT	4	100648
61	WASHER	4	108426
62	LOCK WASHER	4	100169
63	NUT	4	100448
64	WASHER	4	100069
65	BOLT	4	100109
66	SCREW	8	100358
67	SCREW	4	100216
68	SCREW	4	128032
69	PIPE PLUG	1	100196
70	MOTOR	1	
71	PIPE PLUG	1	100332
72	THUMB SCREW	1	107677
73	BREATHER VENT	1	104447

GEAR BOX PARTS LIST PER MODEL


PUMPS MP71XX-2NX

ITEM NO.	DESCRIPTION	QTY.	PART NO.
5	UNIVERSAL CAM	1	005029
22	STROKE CONTROL ROD	1	001134
23	STROKE ADJUSTER DISK	1	001133
36	BALL BEARING	1	100359
39	PUMP MOUNTING BRACKET	1	001415

PUMPS MP71XX-3NX, MP71XX-4NX

ITEM NO.	DESCRIPTION	QTY.	PART NO.
5	UNIVERSAL CAM	1	004784
22	STROKE CONTROL ROD	1	004787
23	STROKE ADJUSTER DISK	1	004857
36	BRONZE BEARING	1	005198
37	BEARING, SLEEVE	1	104735
39	PUMP MOUNTING BRACKET	1	004852

CROSS SECTION (HEAD AREA) MP7120-2N5,-2N8



LIQUID HEAD PARTS LIST PER MODEL

FOR PUMPS: MP7100, 120, 130, 150, 180			-2N3	-2N5	-2N8
ITEM NO	DESCRIPTION	QTY.	PART NO.	PART NO.	PART NO.
25	PLATE, HEAD, #2	1	N/A	004858	004858
26	LIQUID HEAD #2 316SS	1	0047959	N/A	N/A
26	LIQUID HEAD, #2, PVC	1	N/A	004950	N/A
26	LIQUID HEAD, #2, PVDF	1	N/A	N/A	004951
27	DIAPHRAGM , #2 ASSEMBLY	1	104743	104743	104743
28	BACK-UP PLATE #2	1	004774	004774	004774
29	PUMP HEAD ADAPTER, #2	1	004797	004797	004797
46, 47	CHECK VALVE ASSEMBLY, 1/2" NPT, 316SS	2	005011	N/A	N/A
46, 47	CHECK VALVE ASSEMBLY, 1/2" NPT, PVC	2	N/A	003279	N/A
46, 47	CHECK VALVE ASSEMBLY, 1/2" NPT, PVDF	2	N/A	N/A	003332
74	HEX HEAD BOLT	8	N/A	128033	128033
74	SOCKET HEAD CAP SREW	8	100207	N/A	N/A
64	FLAT WASHER	8	N/A	100069	100069

LIQUID HEAD PARTS LIST PER MODEL

FOR PUMPS: MP7100, 120, 130, 150, 180			-3N3	-3N5	-3N8
ITEM NO	DESCRIPTION	QTY.	PART NO.	PART NO.	PART NO.
25	PLATE, HEAD, #3	1	N/A	004859	004859
26	LIQUID HEAD #3 316SS	1	004799	N/A	N/A
26	LIQUID HEAD, #3, PVC	1	N/A	004877	N/A
26	LIQUID HEAD, #3, PVDF	1	N/A	N/A	004809
27	DIAPHRAGM , #3 ASSEMBLY	1	127160	127160	127160
28	BACK-UP PLATE #3	1	004794	004794	004794
29	PUMP HEAD ADAPTER, #3	1	004808	004808	004808
30	SPACER NUT	1	005070	005070	005070
46, 47	CHECK VALVE ASSEMBLY, 1" NPT, 316SS	2	005032	N/A	N/A
46	CHECK VALVE ASSEMBLY, 1" NPS PVC, DISCHARGE	1	N/A	005106	N/A
47	CHECK VALVE ASSEMBLY, 1" NPS PVC, SUCTION	1	N/A	005108	N/A
46	CHECK VALVE ASSEMBLY, 1" NPS, PVDF, DISCHARGE	1	N/A	N/A	005110
47	CHECK VALVE ASSEMBLY, 1" NPS, PVDF, SUCTION	1	N/A	N/A	005112
53	SOCKET HEAD CAP SCREW	12	120831	120831	120831
54	HEX NUT	8	100642	100642	100642
55	LOCK WASHER	12	100217	100217	100217
56	FLAT WASHER	4	106087	106087	106087
57	HEX HEAD BOLT	8	104678	104678	104678
75	O-RING KIT (USED WITH PVC & PVDF CHECK VALVES)	1	N/A	129300	129300

FOR PUMPS: MP7100, 120, 130, 150, 180			-4N3	-4N5	-4N8
ITEM NO	DESCRIPTION	QTY.	PART NO.	PART NO.	PART NO.
25	PLATE, HEAD, #4	1	N/A	004862	004862
26	LIQUID HEAD #4 316SS	1	4810	N/A	N/A
26	LIQUID HEAD, #4, PVC	1	N/A	004878	N/A
26	LIQUID HEAD, #4, PVDF	1	N/A	N/A	004811
27	DIAPHRAGM , #4 ASSEMBLY	1	128035	128035	128035
28	BACK-UP PLATE #4	1	005093	005093	005093
29	PUMP HEAD ADAPTER, #4	1	005091	005091	005091
30	SPACER NUT	1	005070	005070	005070
46, 47	CHECK VALVE ASSEMBLY, 1 1/2" NPT, 316SS	2	005096	N/A	N/A
46	CHECK VALVE ASSEMBLY, 1 1/2" NPS, PVC, DISCHARGE	1	N/A	005098	N/A
47	CHECK VALVE ASSEMBLY, 1 1/2" NPS, PVC, SUCTION	1	N/A	005100	N/A
46	CHECK VALVE ASSEMBLY, 1 1/2" NPS, PVDF, DISCHARGE	1	N/A	N/A	005102
47	CHECK VALVE ASSEMBLY, 1 1/2" NPS, PVDF, SUCTION	1	N/A	N/A	005104
53	SOCKET HEAD CAP SCREW	12	120831	120831	120831
54	HEX NUT	8	100642	100642	100642
55	LOCK WASHER	12	100217	100217	100217
56	FLAT WASHER	4	106087	106087	106087
57	HEX HEAD BOLT	8	104678	104678	104678
75	O-RING KIT (USED WITH PVC & PVDF CHECK VALVES)	1	N/A	129301	129301

SECTION IV

MOTOR OPERATING CONDITIONS

7.0 The normal temperature rise for standard motors is 40°C above ambient temperature and, thus, it might appear that the motor is operating at a higher than normal temperature. This situation is normal.

As a precaution against motor overheating, it is recommended that the pump be located where adequate ventilation is available, It is also recommended that a **MOTOR STARTER WITH THE PROPER OVERLOAD PROTECTION BE SUPPLIED AS AN ADDITIONAL SAFETY DEVICE.**

SECTION V

TROUBLESHOOTING CHART

SYMPTOMS	CAUSES	REMEDIES
1. Pump Motor Will Not Operate.	A. Blown Fuse.	Check for short circuit or overload
	B. Open thermal overload device in starter.	Reset.
	C. Low liquid level in tank (where low level cut-off is used).	Fill tank.
	D. Broken wire.	Locate and repair.
	E. Low voltage.	Check for too light wiring.
	F. Oil "frozen" in pump.	Thaw out.
2. Pump Does Not Deliver Rated Capacity	A. Starved suction.	Look for blockage in suction line.
	B. Leaky suction piping.	Replace suction piping with larger size. Pressure test, repair or replace defective piping.
	C. Excessive suction lift.	Rearrange equipment location to reduce suction lift.
	D. Liquid too close to boiling point.	Lower temperature or increase suction pressure slightly.
	E. Worn or dirty valves or seats, or both	Clean or replace valve assembly.
	F. Viscosity of liquid too high	1. Reduce viscosity by heating or other means 2. Increase size of suction piping 3. Increase suction pressure slightly
	G. Low discharge pressure	A minimum discharge pressure of 25 psi is required to insure proper capacity control Repair or replace piping.
3. Pump delivers erratically.	A. Leaky suction line.	Clean or replace valve assembly.
	B. Worn or dirty valves or seats, or both.	Increase backpressure.
	C. Excessive excursion of ball valves from seats (indicated by ball chatter).	Increase suction pressure.
	D. Insufficient suction pressure	Raise tank level.
	E. Liquid too close to boiling point,	Reduce temperature or raise suction pressure.
	F. Leaky system relief valve.	Repair or replace relief valve
4. Motor overheats thermal overload activates,	A. Power supply does not match motor.	Check power supply against motor nameplate data.
	B. Overload caused by operating pump beyond rated capacity	Check operating pressure against pump manufacturer data plate maximum rating
5. Noisy Operation	A. Pump Valves.	Valves must move to open and close, and they will make a clicking noise as they operate. These noises are sometimes amplified by natural resonances in piping system. They are usually indications of normal valve functioning.
		Fluid compressibility causes reversal of load on gears at end of pressure stroke, Not considered detrimental.
5.1. In Pump		
5.2. In Gear Reducer	A. Pounding noise at high discharge pressure	Replace diaphragm
6. Oil level Low	A. Flexible diaphragm punctured	

SPARE PARTS KITS

ITEM NO.	DESCRIPTION	QTY.	PART NUMBER	
27	DIAPHRAGM #2 ASSEMBLY	1	104743	KIT NUMBER 005178 MP71XX-2N3
46, 47	CHECK VALVE ASSEMBLY 1/2" NPT	2	005011	

ITEM NO.	DESCRIPTION	QTY.	PART NUMBER	
27	DIAPHRAGM #2 ASSEMBLY	1	104743	KIT NUMBER 005179 MP71XX-2N5
46, 47	CHECK VALVE ASSEMBLY 1/2" NPT	2	003279	

ITEM NO.	DESCRIPTION	QTY.	PART NUMBER	
27	DIAPHRAGM #2 ASSEMBLY	1	104743	KIT NUMBER 005180 MP71XX-2N8
46, 47	CHECK VALVE ASSEMBLY 1/2" NPT	2	00003332	

ITEM NO.	DESCRIPTION	QTY.	PART NUMBER	
27	DIAPHRAGM #3 ASSEMBLY	1	127160	KIT NUMBER 005181 MP71XX-3N3
46, 47	CHECK VALVE ASSEMBLY 1" NPT	2	005032	

ITEM NO.	DESCRIPTION	QTY.	PART NUMBER	
27	DIAPHRAGM #3 ASSEMBLY	1	127160	KIT NUMBER 005182 MP71XX-3N5
46	CHECK VALVE ASSEMBLY 1" NPS DISCHARGE	1	005106	
47	CHECK VALVE ASSEMBLY 1" NPS SUCTION	1	005108	
75	O-RING KIT	1	129300	

ITEM NO.	DESCRIPTION	QTY.	PART NUMBER	
27	DIAPHRAGM #3 ASSEMBLY	1	127160	KIT NUMBER 005183 MP71XX-3N8
46	CHECK VALVE ASSEMBLY 1" NPS DISCHARGE	1	005110	
47	CHECK VALVE ASSEMBLY 1" NPS SUCTION	1	005112	
75	O-RING KIT	1	129300	

ITEM NO.	DESCRIPTION	QTY.	PART NUMBER	
27	DIAPHRAGM #4 ASSEMBLY	1	128035	KIT NUMBER 005184 MP71XX-4N3
46, 47	CHECK VALVE ASSEMBLY 1 1/2" NPT	1	005096	

ITEM NO.	DESCRIPTION	QTY.	PART NUMBER	
27	DIAPHRAGM #4 ASSEMBLY	1	128035	KIT NUMBER 005185 MP71XX-4N5
46	CHECK VALVE ASSEMBLY 1 1/2" NPS DISCHARGE	1	005098	
47	CHECK VALVE ASSEMBLY 1 1/2" NPS SUCTION	1	005100	
75	O-RING KIT	1	129301	

ITEM NO.	DESCRIPTION	QTY.	PART NUMBER	
27	DIAPHRAGM #4 ASSEMBLY	1	128035	KIT NUMBER 005186 MP71XX-4N8
46	CHECK VALVE ASSEMBLY 1 1/2" NPS DISCHARGE	1	005102	
47	CHECK VALVE ASSEMBLY 1 1/2" NPS SUCTION	1	005104	
75	O-RING KIT	1	129301	

