

Liquid End Sheet

LE-92V

When pumping solutions, make certain that all tubing is securely attached to the fittings. It is recommended that tubing or pipe lines be shielded to prevent possible injury in case of rupture or accidental damage. Always wear protective clothing and face shield when working on or near your metering pump.

Note: See parts list for materials of construction

A. INSTALLING INJECTION CHECK VALVE

1. The purpose of the injection check valve is to prevent backflow from the treated line.
2. A 1/2" NPT female fitting with sufficient depth will accept the injection check valve.
3. To insure correct seating of the ball inside the injection check valve, the injection check valve should be installed upwards (vertically) into bottom of the pipe.

B. CONNECTING DISCHARGE TUBING

NOTE:

Cut tubing to length needed for discharge line.

1. Route tubing from the injection check valve to the metering pump, making sure it does not touch hot or sharp surfaces, or is bent so sharply that it kinks.
2. Slide the small end of the coupling nut onto tubing, then slide on the clamp ring.
3. Push tubing on the valve housing nozzle so that tubing flares out and butts up against valve housing and will not go any further.
4. Slide the clamp ring and coupling nut to the threads and engage. While pushing the tubing onto the valve housing nozzle, tighten the coupling nut by hand until tubing is held securely in place.

**Excessive force will crack or distort fittings.
DO NOT USE PIPE WRENCH.**

C. CONNECTING SUCTION TUBING

1. Cut suction tubing to a length so that the foot valve hangs just above the bottom of the solution container. Maximum recommended vertical suction lift is 5 ft (1.5 m).
2. Follow same procedure in connecting suction tubing to suction valve and foot valve (see **B. Connecting Discharge Tubing**).

D. PRIMING

1. Temporarily remove tubing from the injection check valve and hold the end of tubing so it is above the level of the pump.
2. Start pump. Set at 80% speed and 100% stroke.
3. As soon as solution is visible through translucent discharge tubing, just past the discharge valve, stop the pump.
4. The pump is now primed.
5. Reconnect tubing to the injection check valve.

NOTE:

- (a) Pump is normally self-priming if suction lift is not more than 5 ft (1.5 m), valves in the pump are wet with water (pump is shipped from factory with water in pump head) and the above steps (**D. Priming**) are followed.
- (b) If the pump does not self prime, remove discharge valve housing and ball and pour water or solution slowly into discharge port until head is filled. Follow step **D. Priming** thereafter.



8 Post Office Square
Acton, MA 01720 USA
TEL: (508) 263-9800
FAX: (508) 264-9172
<http://www.lmipumps.com>



Replaces same of Rev C 3/84
1234.D 5/97

NOTE:

Threaded connections into pump head are 3/4"-16 straight threads. **Do not use Teflon tape.** These joints are sealed by seal ring valve seats (Item 4 on exploded view).

1. Maximum pump pressure rating is reduced by 25 psi (1.7 bar) with anti-syphon spring installed.
2. Do not remove anti-syphon spring if pressure at injection point is less than 20 psi (1.4 bar).

LE 92V

Ref. No.	Part No.	Description	Quantity
2	10339*	Spring, PVDF Coated	1
3	10338*	Ball, Ceramic	4
4	10207*	Seal Ring, Viton	4
5	10292	Valve Seat, PVC or Polypropylene	1
6	10299	Coupling Nut, gray PVC	4
7	10342-16	Tubing, Polyethylene, .375" OD	1
8	10293	Valve Housing, PVC or Polypropylene	2
9	10340	Screw, 10-24 x 3/4" S.S.	4
10	10302*	Liquifram, 0.9 Si Teflon Face	1
11	10213	Head, gray PVC	1
12	10322	Weight, Ceramic	1
13	10978	Foot Valve Seat, black Polypropylene	1
14	10123	Strainer, Polypropylene	1
15	26950	Injection/Back Pressure Valve Assembly	1
16	10507	Discharge Valve Assembly	1
17	10508	Suction Valve Assembly	1
18	10509	Foot Valve Assembly	1
19	10510	Head Assembly, LE-92V	1
22	26839	Valve Seat, CFR, PVDF	1
25	25449	Flapper Nut, PVC	1
26	10290	Flapper, Viton, yellow dot	1
27	26841	Injector Fitting, CFR PVDF	1
28	26136	Clamp Ring	3

